

herkulesTM

G520

Part# 1003058-17
2/7/2023



Made in USA

OWNERS MANUAL



This manual contains important information concerning the installation and operation of the gun washers listed above.
Read manual thoroughly and keep for future reference



Herkules Patent Numbers

These products have patent protection under one or more of the following patent numbers:

9422142, 8733508, 8714524, 866247, 8052120, 7070167, 5485860, 5193561, 5174317, 4960142, 4793369 and Patents Pending

Website: www.herkules.us
E-mail: info@herkules.us

Herkules Equipment Corporation
2760 Ridgeway Court
Walled Lake, MI 48390-1662 USA

Toll Free: 800-444-4351
Phone: 248-960-7100
Fax: 248 960-7109

Table of Contents

Warranty	3
Model Information	4
Warnings	5-6
Installation	7
Operation	8-11
Preventive Maintenance	12
Troubleshooting	13
Pump Reset Instructions	14-15
Drawings with Part Lists	16-18
G520 Schematic	19

Herkules Equipment Corporation

A U.S.-based manufacturer, Herkules Equipment Corporation offers a diverse line of products that support multiple industries by improving efficiency, productivity, ergonomics, comfort, and safety in the work environment. The company consists of the three product lines: Herkules, Enkon and BossLifts.

Since 1985, Herkules has designed, engineered and manufactured quality products at our Walled Lake, Michigan facility. Our company supports our products after delivery, with U.S. based customer service, and replacement parts, enabling our customers to proceed with confidence.

To learn more about Herkules, visit <http://herkules.us>. Contact us at info@herkules.us with any questions or concerns.

Thank you for purchasing a Herkules product!

Warranty

IMPORTANT NOTICE: if you have a problem with your Herkules product,

DO NOT RETURN TO PLACE OF PURCHASE

Contact Herkules: by phone 1-800-444-4351; by email, info@herkules.us; or on the web at herkules.us/contact-us.

At Herkules we take great pride in the construction of our American-made products, and we stand behind their reliability. Our limited liability warranty coverage for Paint Gun Washers warranties the unit for a period of 12 months. Washer pumps have a separate warranty; the Herkules 338 pump is protected for a period of 2 years from the date of purchase. All other pumps, including rinse pumps, are warrantied for 12 months.

This warranty does not apply to equipment damaged from accident, abuse, overload, misuse, negligence, improper installation, abrasive or corrosive materials, or shipping damage.

In the event of product failure, the defective item must be returned, freight prepaid, to the Herkules manufacturing plant for repair or replacement. If repairs are required, Herkules will not be liable for these repairs to take place in the field regardless of the application. Proof of purchase and date of purchase must be confirmed. An RGA* (Returned Goods Authorization) and written approval from Herkules must be obtained before any goods can be shipped to Herkules. We reserve the right to Determine whether failure is due to defective material, normal wear, and / or other causes.


There are no warranties which extend beyond the description on the face hereof. Herkules disclaims any warranty of merchantability or fitness for a particular purpose in connection with the Buyer's purchase of any Product under this agreement. Damages are limited to the sales price of the Herkules system. The terms and conditions herein represent the entire agreement between Herkules and the Buyer. Any prior / future representations do not apply.

*To obtain a RGA, contact Herkules at 1-800-444-4351 and have the item model, serial numbers, and invoice number if applicable.

Upon receipt of your equipment, please write your purchase information below. Please retain this manual for your records.

Serial Number	_____	Model Number	_____
Purchase Date	_____	Distributor (if applicable)	_____

Model Information



NOTE: Dimensions listed are overall measurements.

Model	Description	Weight lbs/(kg)	Dimensions in./(mm)			
			A	B	C	D
G520	Two independently operating washers. The left side is for manually cleaning water borne paints and the right side is for timed automatic cleaning of either waterborne or solvent based paints	141 (64)	51.38 (1305)	15.38 (391)	20.25 (514)	41.38 (1051)

Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.



WARNING



EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture, malfunction, or start unexpectedly and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags, and labels before operating the equipment.
- Use the equipment only for its intended use.
- Do not alter or modify this equipment.
- Do not exceed the maximum working pressure of the lowest rated system component.
- Do not operate the gun washer at a pressure above the maximum working pressure rating of the gun(s) being cleaned.
- Route the hoses away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not use the hoses to pull the equipment.
- Do not move pressurized equipment.
- Use fluids or solvents that are compatible with the equipment wetted parts. Read the fluid and solvent manufacturer's warnings.
- Comply with all applicable local, state, and national fire, electrical, and other safety regulation.



PRESSURIZED EQUIPMENT HAZARD

Spray from hose leaks, ruptured components, or from operating the gun washer with an open lid can splash fluid in the eyes or on the skin and cause serious injury.

- A safety device has been installed to shut off the pump when the gun washer lid is opened.
Do not tamper with, or alter this device.
- Do not prop the gun washer lid open with an object or by any other means.
- Open the gun washer lid slowly.
- Do not stop or deflect fluid leaks with your hand, body, glove, or rag.
- Tighten all fluid connections before operating the equipment.
- Replace worn, damaged, or loose parts immediately.



WARNING



FIRE AND EXPLOSION HAZARD



Improper grounding, poor air ventilation, open flames, or sparks can cause a hazardous condition and result in fire or explosion and serious injury.

- Ground the equipment. See Installation for grounding procedure.
- Provide fresh air ventilation to avoid the build up of flammable fumes from the cleaning solution.
- Extinguish all open flames or pilot lights in the gun washer area.
- Disconnect all electrical equipment in the gun washer area.
- Keep the gun washer area free of debris, including cleaning solutions, rags, and gasoline.
- Do not turn on any light switch in the gun washer area while operating or if fumes are present.
- Do not smoke in the gun washer area.
- Do not operate a gasoline engine in the gun washer area.
- Follow the gun manufacturer's solvent and other cleaning recommendations.
- Use solvent with the highest possible flash point.
- If there is any static sparking while using the equipment, **stop operation immediately**. Identify and correct the problem.
- Drain the cleaning solution into a proper storage container when gun washer(s) is not in use.



TOXIC FLUID HAZARD

Hazardous fluids or toxic fumes can cause serious injury or death if splashed in eyes or on the skin, swallowed, or inhaled.

- Know the specific hazards of the fluid you are using. Read the fluid manufacturer's warnings.
- Store hazardous fluid in an approved container. Dispose of hazardous fluid according to all local, state and national guidelines.
- Wear the appropriate protective clothing, gloves, eyewear and respirator.
- Pipe and dispose of the exhaust air safely. If diaphragm fails, the fluid may be exhausted along with the air.

Installation

Installing the Gun Washer


Place gun washer on a level surface in a properly ventilated paint mixing room or paint booth.

Grounding the Gun Washer

- 1) Connect the ground wire on the gun washer's pump to a true earth ground.
- 2) Ground all equipment used or located in the gun washer area.


Connecting the Air Line

- 1) Install a 1/4 in. npt male coupler (that is compatible with the quick disconnect of your air supply line) into the air supply port of the filter/regulator (located on the back right leg.)
- 2) Connect air line with at least 75 psi to the coupler. Filter/regulator is preset. **DO NOT ADJUST.**
- 3) Connect Air Gun (P/N 13800) to fitting on left leg (to bulkhead marked with Air Gun Sticker).



Whip Line Installation

- 1) Whip Line kit is located in a baggie included with the gun washer.
- 2) Remove hex plug from the left side of the gun washer.
- 3) Screw on street elbow to the bulkhead, aim the open end of the fitting to the floor.
- 4) Screw hose end into the street elbow.
- 5) Screw on quick disconnect coupler to the other end of the hose. (This coupler is customer supplied and should match the fittings on the guns to be cleaned).




Operation

Manual cleaning of waterborne paints (left side)

Connecting the water to the washer

- 1) Insert the filter mount frame into the bucket.
- 2) Fill with distilled water until the water level reaches the bottom of the filter support cross arms.
- 3) Connect the large filter bag to the filter mount frame so that the bottom of the filter is resting on the filter support.
- 4) Insert the small filter bag into the large bag and connect to the filter mount frame.
- 5) Place the bucket under the Gun Washer and insert the pick up tube between the bucket wall and the filter.
- 6) Open ball valve.


Filter mount
frame



Operation

Preparing the Equipment to be Washed

- 1) Remove paint cup or paint line and the air line from the paint gun.
- 2) Drain excess paint from cup and gun into a separate container.
- 3) Remove all gauges and regulators from painting equipment.
- 4) Remove the air cap/fluid tip from the paint gun (for manual cleaning only).
- 5) Connect the whip line to the spray gun using the customer supplied quick disconnects.



CAUTION

All pressure gauges must be removed before placing the equipment in the gun washer to avoid damaging the gauges (for Automatic Cleaning only).

Cleaning the Equipment

- 1) Activate the timer on the left leg.
- 2) To activate manual clean brush, turn handle on valve until water starts to flow. Flow can be adjusted using the handle on the manual brush valve.
- 3) Position the spray gun so the pressure clean nozzle is inserted into the paint channel of the spray gun. Lift up the gun while squeezing the trigger to activate the push valve. This action sends a pressurized flow of water through the gun's paint channel.

Clean rinse

- 1) Fill an additional bucket (not supplied) with distilled water.
- 2) Insert the clean rinse inlet tube (located on the left side of the Gun Washer) in the bucket.
- 3) Set the rinse / agitator switch (on the front of the Gun Washer) to rinse.
- 4) Position the spray gun so the clean rinse nozzle is inserted into the paint channel of the spray gun.
- 5) Squeeze the trigger of the spray gun while lifting up the gun. This action sends a pressurized flow of clean water through the gun's paint channel.

Note: Position the spray gun so that the flow of water exiting the paint gun is contained within the Gun Washer tub.

- 6) Return the rinse / agitator switch to the neutral position when finished.
- 7) Use the air gun to dry off any wet components.

Operational Note:

- 1) The left (waterborne) side of the gun washer is set up to pump fluid on demand when the timer is active. If the draw bucket is empty, the pressure clean nozzle and manual brush will blow air.

Note: Re-use/re-used the cleaning solution / water mixture until it becomes tacky to the touch. Dispose of all waste materials according to local, state, and federal regulations.


Operation

Filtering Dirty water (optional)

- 1) Close ball valve.
- 2) Remove the cleaning platform from inside of the left tank.
- 3) Pour the dirty paint mixture to be recycled into the tank. Do **not** exceed the 5 gallon capacity of the tank.
- 4) Add flocculant / coagulant to the dirty paint mixture. (Herkules CoAgent (CA01) recommended. Herkules CA01 sample included with unit.
- 5) Set the switch on the front of the Gun washer to Agitator. Stir mixture for 30 seconds during agitation. Allow the dirty paint mixture / flocculant mix to agitate for 30 to 120 seconds (dependent upon quality of flocculant). Let the mixture sit for 30 seconds. Return the agitator switch to the Off position.

Note: Repeat process if adequate separation does not occur (dependent upon quality of flocculant).

- 6) Open the ball valve to allow the mixture to drain through the filter bags. The filter bags capture the paint debris, and the bucket captures the filtered cleaning solution / water mixture that can be re-used for cleaning.
- 7) Empty the paint waste out of the inner filter. Place inner filter back on the filter holder for up to 10 uses.
Note: place solid waste onto a piece of cardboard to finish drying. This will speed the process as the cardboard will absorb the moisture from the paint debris.
- 8) Close the ball valve. Replace filter bags (P/N 1003348 & P/N 1003351) as needed.



- 9) Dispose of all waste materials according to all local, state, and federal regulations.
- 10) Wipe inner tank after each use.

Automatic cleaning of all paints (right side)

Note: Once right side has been used for solvent based paints, it cannot be used for waterborne paints. Once right side has been used for waterborne paints it cannot be used for solvent based paints.

Connecting the Solvent to the Washer

Insert the drain pipe and siphon tube into a fresh 5 gallon solvent can and secure the plug in the opening.

The can must contain at least 2.5 gallons of solvent to pump properly. Use a high quality solvent.

Placing Equipment in the Gun Washer

To clean guns not mentioned here, use the long or short stem supports as needed. For questions or adapter kits, contact your paint gun washer distributor.

Siphon Feed Guns

Place the gun siphon tube on the short stem support.

Gravity Feed Guns (HVLV)

Place the long stem support over the short stem support. Place paint inlet of gun on long stem support. Place the air cap assembly over the air inlet of the gun to prevent solvent from entering the passage.

Operation

Preparing the Equipment to be Washed


- 1) Remove paint cup or paint line and the air line from the paint gun.
- 2) Drain excess paint from cup and gun.
- 3) Remove all gauges and regulators from painting equipment.
- 4) Lock the gun trigger in the open position by placing the trigger lock around the gun handle and trigger.

Pressure Feed Guns


Place long stem support over the short stem support.
Place paint inlet of gun on long stem support.

Pots and Cups

Place a pot or a cup on the cup holder.



Note:
Only one gun & one cup shown for clarity.



Operating the Gun Washer

- 1) Make sure wire trigger locks and other accessories are inside the gun washer tank.
- 2) Place equipment in the tank according to the diagrams shown on page 8.
- 3) Close the gun washer lid.
- 4) Turn the timer knob clockwise 90 degrees to start the gun washer. The gun washer will run for 90 seconds. Turning the timer knob less than 90 degrees will reduce the timing cycle. Paint equipment will clean in 60 to 90 seconds.
- 5) If the lid is opened prior to the end of the timing cycle, the safety air cutoff switch will stop the gun washer. The gun washer will start again when the lid is closed if time remains on the timer.
Note: Open the lid slowly to minimize vapor escape.
- 6) Remove the equipment from the gun washer and wipe off any remaining solvent.


Preventative Maintenance

To keep your machine working efficiently and effectively, please follow these directions.

- 1) Always drain excess paint from cup or pot before placing in gun washer.
- 2) Drain paint sludge from 5 gallon solvent can weekly.
Do this after a weekend so the sludge has settled.
 - Access the solvent can by removing the drain hose from the can, then remove the nylon plug from the can.
 - Pour the solvent into a second container and drain the sludge into a disposal container. Refill can from the second container and add solvent to reach the 2.5 gallon minimum, or the can half-full.
 - Clean siphon tube with cloth and brush to remove residue.
- 3) Replace Filter/Regulator yearly. (#11345)
- 4) Change solvent completely when objects being cleaned become tacky to the touch.
- 5) Clean inside of tub and internal manifold.

CAUTION

Do not change the setting of the filter/regulator; Doing so could damage the filter/regulator or pump.



Troubleshooting

Problem	Possible Solution	
Gun washer will not turn on. (automatic)	1	Make sure the air line is properly connected with at least 75 psi.
	2	Make sure lid is fully closed. Make sure the lid rod actuator is making full contact with the limit valve on the right rear leg.
	3	Check all air connections to ensure that there are no leaks.
	4	Make sure timer cam is engaging the limit valve on the right front leg.
	5	Make sure timer is on and functioning correctly.
Pump turns on but wash water does not flow. (manual)	1	Make sure wash bucket is not empty.
	2	Make sure the filter at the end of the pick up tube is completely submerged in water.
	3	Check all fluid connections to ensure that there are no leaks.
Gun washer turns on but pumps slowly or not at all.	1	Make sure intake filter is not clogged (Clean or replace).
	2	Make sure the air line is properly connected with at least 75 psi. Air pressure is regulated at 75 psi.
	3	Check all air connections to ensure that there are no leaks.
	4	Make sure there is 2.5 gallons of clean solution in the gun washer. The cleaning solution should be an inch above the intake filter.
	5	Make sure lid is fully closed. Make sure the lid rod actuator is making full contact with the limit valve on the right rear leg.
	6	Make sure manifold nozzles and stem supports are not clogged.
Gun washer will not shut off	1	Make sure timer cam is moving. If it's not, slightly loosen the nuts holding the limit valve on the right front leg of the stand. Reposition valve and tighten nuts.
	2	Make sure limit valves located on the right and left legs of the stand are not stuck in closed position.
	3	Make sure line is hooked in correctly to the limit valve.
No flow through the manual brush.	1	Make sure wash bucket is not empty.
	2	Make sure the filter at the end of the pick up tube is completely submerged in water.
	3	Check all fluid connections to ensure that there are no leaks.
	4	Make sure valve handle is not closed all the way.

Pump Reset Instructions



If a pump has locked up and needs to be reset, follow these instructions to restore pump function.

Newer generation pump access:

Newer versions of the Herkules G520 Gun Washer have a square access hole located on the legs to allow access to the pump reset screw.

Older generation pump access.

Older versions of the Herkules G520 Gun Washer do not have the access hole and will require the pump be rotated to gain access to the pump reset screw.

- 1) Remove the 7/16" nut, bolt, and lock washer from the front pump mount. Loosen the bolt on the other side (but do not remove).



- 2) With the front bolt removed and the back bolt loosened, rotate pump away from the leg to expose the side that was up against the leg.




- 3) Using a flat head screwdriver, insert the head into the slot on the reset screw head on pump. Twist either direction approximately 2 degrees until a click sound is heard. May need to rotate both ways to accomplish reset.



- 4) Ensure there is fluid in the draw bucket for the pump, and start cycling pump to ensure pump has been successfully reset.
- 5) If pump is still stalled, try rotating reset screw again. Test unit to ensure it is working properly.
- 6) Rotate pump back into position and replace all hardware to mount pump down. Tighten backside screw.

G520 Parts Layout




G520 Parts Layout

Part #	Description	Quantity
1 13129	Manifold Assembly	1 EA
2 13107	Shroud assembly	1 EA
3 14141	Whip Line Assembly	1 EA
4 13800	Air Gun Assembly	1 EA
5 13901	Cleaning Platform	1 EA
6 21136	Left Leg Assembly	1 EA
7 13123	Pump Assembly - Solvent	2 EA
8 12509	Air Cap Assembly	2 EA
9 13053	Filter Assembly	1 EA
10 13124	Pump Assembly - Water	1 EA
11 1002914	Bucket 5-Gallon	1 EA
12 1003348	Inner Filter Bag	1 EA
13 1003351	Outer Filter Bag	1 EA
14 1002967	Filter Mount Frame	1 EA
15 1002912	Toggle Valve Assembly	1 EA
16 13125	Right Leg Assembly	1 EA
17 19279	Right Lid Assembly	1 EA
18 1002969	Frame	1 EA
19 1002644	Bulkhead 1 - Brass	2 EA
20 1002654	Hose Barb 3/8 x 3/8 NPT	1 EA
21 1002779	Elbow 1/4 NPT - Brass	4 EA
22 002-134	Agitator Nozzle	1 EA
23 62	Adaptor 1/2 NPT x 3/8 NPT	1 EA
24 64PE	Hose 1/2 - Black PE	23 IN.
25 T25	Hose fitting 5/32 x 1/4 NPT	1 EA
26 002-118	Fitting PTC 90 Deg Swivel 1/4 x 1/4 NPT	2 EA
27 1000563	Brush Solvent Manual	1 EA
28 11243	Filter Assembly	1 EA
29 1002572	Actuator Rod 24"	1 EA
30 19278	Tub Assembly	2 EA
31 1003272	Lid	1 EA
32 1007865	Pump Bracket	1 EA
33 19454	Nozzle	2 EA
34 13430	Rinse Pump	1 EA

Note: Replacement Inner and Outer Waterborne Recycling Bags can be ordered on-line at www.herkules.us/herkules/parts

G520 Manifold Layout



Part #	Description	Quantity
1	1008136 Bent Manifold Tube - Stainless	1 EA.
2	10284 Tee 1/4 NPT - Brass	1 EA.
3	12509 Air Cap Assembly - Brass and Stainless	2 EA.
4	1000115 Compression Fitting 1/8 - Brass	1 EA.
5	1002422 Cup Holder - Stainless	2 EA.
6	1002529 Manifold - Stainless	1 EA.
7	1002651 E-ring - Stainless	2 EA.
8	002-143 Compression Fitting 1/4 - Brass	1 EA.
9	002-192 Rivet	1 EA.
10	22BA Trigger Lock Assembly	2 EA.
11	53A Stem Support Male	2 EA.
12	53B Stem Support Female	2 EA.
13	54 Full Jet Nozzle - Brass	2 EA.
14	54P1 Full Jet Nozzle - Kynar	6 EA.
15	C12D Tee 1/8 NPT - Brass	2 EA.
16	C9A Nipple 4-1/2" - Brass	2 EA.
17	M6 Elbow 1/8 NPT - Brass	3 EA.
18	002-121A Wire Assembly	1 EA.

Note: Parts are shown for reference purposes only and are not necessarily part of a Herkules assembly.

