



INSTRUCTIONS:

1. INSTALL (4) CASTERS THROUGH LOWER SHELF, THEN THROUGH LOWER LEG ASSEMBLY AND INSTALL WASHER AND NUT.
2. POSITION TOP PEGBOARD ASSEMBLY INSIDE LOWER LEG ASSEMBLY "C" CHANNEL & SECURE USING 4" BOLT, 2 WASHERS & NUTS
3. INSTALL (1) TOOL BIN PER SIDE USING (4) 1/2" BOLTS, WASHERS & NUTS
4. SET TOOL TRAY INSIDE BRACKETS ON TOP OF THE UNIT.



## TOOLMATE ASSEMBLY INSTRUCTIONS

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF QSP. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QSP IS PROHIBITED.