


ZRM Model

#	Description
1	Cylinder
2	Plunger
3	*Backup Ring
4	*O-ring
5	Nut
6	Spring
7	Washer
8	Screw
9	Retaining Ring
10	Half Coupler
RP	Repair Kits (All *)



ZRB Model

#	Description
1	Cylinder
2	Plunger
3	Retaining Ring
4	*U-cup Ring
5	*Backup Ring
6	*Wiper
7	Spring
8	Washer
9	Screw
RP	Repair Kits (All *)

