



Repair Parts

| No. | Description | Qty. | Part No. | No. | Description | Qty. | Part No. |
|-----|----------------------------------|------|----------|-----|-------------------------------|------|----------|
| 1. | Lock-On Angle Chuck | 4 | 11157 | 11. | Self Tap 10-24 x .500 Long | 4 | 1055 |
| 2. | 3/8" Air Regulator | 1 | 11158 | 12. | 1/4" Locknut | 4 | 226 |
| 3. | Two Stage Coupler | 1 | 11159 | 13. | 5/16" Flat Washer | 8 | 445 |
| 4. | 1/4" Nipple (2) | 2 | 11160 | 14. | 1/4" Hex Head Bolt x .75 Long | 4 | 903 |
| 5. | 3/8" to 1/4" Bushing | 2 | 772 | 15. | 1/4" Ball Valve 4.103 | 1 | 4.103 |
| 6. | Back Mount Gauge | 1 | 11162 | 16. | 3/8" 300 PSI 3' Hose | 1 | 11166 |
| 7. | Nut and Washer Eye Bolt Assembly | 2 | 11163 | 17. | Four Line Air Manifold | 1 | 11167 |
| 8. | Female to Female Ball Valve 1/4" | 1 | 12572 | 18. | 1/4" 200 PSI 25' Hose | 4 | 11168 |
| 9. | Regulator Housing | 1 | 6390 | 19. | Cover Handle | 1 | 6417 |
| 10. | Rubber Feet | 4 | 12607 | | | | |



TIRE SERVICE INTERNATIONAL

Order parts from your distributor or jobber. When ordering parts always give the following information: Part Number, Description and Serial Number of Your Machine.