



| No. | Description               |
|-----|---------------------------|
| 1   | Screw M10x16L             |
| 2   | Top Plate                 |
| 3   | *Oil Seal                 |
| 4   | Fasten Nut                |
| 5   | Screw 3/8"x50L            |
| 6   | *Oil Ring                 |
| 7   | Piston Rod                |
| 8   | *Backup Ring              |
| 9   | *Oil Ring                 |
| 10  | Snap Ring                 |
| 11  | Screw Nut M33x22.6L       |
| 12  | Spring                    |
| 13  | Screw M6x31L              |
| 14  | Handle                    |
| 15  | Cylinder                  |
| 16  | Screw                     |
| 17  | Base                      |
| 18  | Screw M6x15L              |
| RP  | Repair Kits (All * Above) |