

Operating manual | Inspection book

including spare parts list

Version: USA

Manual date: 13.01.2020

POWER LIFT HF 3S 8000

Serial No.:



in Germany





	General informations5	5	Operating manual	23
1.1	Lift purpose5	5.1	Positioning the vehicle	23
1.2	Liability5	5.2	Lifting the vehicle	
1.3	Owner/Employer responsibilities5	5.3	Lift synchronization	25
1.4	Lift operator responsibilities6	5.4	Lowering the vehicle	25
1.5	Safety regulations6			
1.6	Safety devices7	6	Behaviour in cases of error	25
1.7	Safety labels affixed to lift8	6.1	Emergency discharge	26
1.8	Protocols9	6.2	Moving onto an obstacle	27
1.9	Set up and test the lift9			
Set (up protocol10	7	Maintenance and care of the lift	27
Tran	sfer protocol11	7.1	Maintenance plan	28
		7.2	Cleaning the lift	33
2	System master sheet12	7.3	Checking the stability of the lift	33
2.1	Manufacturer12			
2.2	Purpose	8	Assembly and commissioning	33
2.3	Changes to the design / construction12	8.1	Set up guidelines	33
2.4	Changing the assembly location12	8.2	Lifting arm assembly	38
		8.3	Lifting arm alignment	38
3	Technical information13	8.4	Commissioning	38
3.1	Technical data13	8.5	Changing the assembly location	38
3.2	Safety devices13			
3.3	Data sheet14	9	Safety inspection	42
3.4	Hydraulic plan16	9.1	Single safety inspection before commissioning	43
3.5	Electrical circuit diagram17	9.2	Regular safety inspection and maintenance	44
		9.3	Exceptional safety inspection	54
A	Installation 22			

Spare parts list 55

1 General informations

Important safety instructions – Save these instructions

1.1 Lift purpose

Nussbaum lifting systems are the result of over 35 years' experience in the automotive lifting industry. The high quality and superior concept ensures reliability, a long Lift lifetime, and a strong economic business solution for your automotive lifting needs. The HF 3S 8000 are a hydraulic asymmetric two-post Lift with a lifting capacity of 8000 pounds. The Lift features a powerful integrated power unit and hard-chromed cylinders. The maximum load distribution is 2000 lbs per arm.

1.2 Liability

To avoid unnecessary damage, injury or death, read all operating instructions carefully. Nussbaum is not liable for any damages, injuries, or deaths resulting from misuse of the Lift. The user carries the risk alone.

There will be no guarantee or liability for incidents involving injuries, death, or damage to equipment if these incidents are the result of one or more of the following:

- Inappropriate use of the Lift to include: Inappropriate installation, operation, and maintenance of the Lift.
- Use of the Lift while security devices are inoperative, not working properly, or are installed incorrectly.
- Failure to follow the operating instructions regarding transport, storage, installation, initiation, operation, and maintenance of the Lift.
- Unauthorized changes to the design and operation of the Lift.
- Wrong or incorrect maintenance practice.
- Catastrophes, acts of God, or external reasons.
- Nussbaum Lifts are warranted with the use of Nussbaum original or replacement parts. Use only replacement parts approved by the original equipment manufacturer or parts meeting original manufacturer specifications. Use of unauthorized parts may void the warranty. For parts, call Nussbaum at 1-704-864-2470.
- It should be recognized that any piece of equipment can be dangerous when operated improperly.

1.3 Owner/Employer responsibilities

Automotive lift institute safety requirements for operation, inspection and maintenance (ANSI/ALI ALOIM)

The Owner/Employer shall insure that lift operators are qualified and that they are trained in the safe use and operation of the lift: ALI SM10-1 safety manual; AL-ST-17; ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirement for Operation, Inspection and Maintenance; ALI/WL Series, ALI Uniform Warning Label Decals/Placards; and in case of frame engaging lifts, ALI/LP-GUIDE, Vehicle Lifting Points/Quick Reference Guide for Frame Engaging Lifts and SAE J2184, Vehicle Lifting Points for Service Garage Lifting.

The Owner/Employer shall establish procedures to periodically inspect the lift in accordance with the lift manufacturer's instructions or ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirements for Operation, Inspection and Maintenance; and the employer shall insure that the lift inspectors are qualified and that they are adequately trained in the inspection of the lift.

The Owner/Employer shall establish procedures to periodically maintain the lift in accordance with the lift manufacturer's instructions or ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirements for Operation, Inspection and Maintenance; and the employer shall insure that the lift maintenance personnel are qualified and that they are adequately trained in the maintenance of the lift.

The Owner/Employer shall maintain the periodic inspection and maintenance records recommended by the manufacturer or ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirements for Operation, Inspection and Maintenance.

The Owner/Employer shall display the lift manufacturer's operating instructions; ALI SM10-1 safety manual; AL-ST-17; ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirement for Operation, Inspection and Maintenance; ALI/WL Series, ALI Uniform Warning Label Decals/Placards; and in case of frame engaging lifts, ALI/LP-GUIDE, Vehicle Lifting Points/Quick Reference Guide for Frame Engaging Lifts; in a conspicuous location in the lift area convenient to the operator.

Additional owner/employer responsibilities

- Shall require that Personal Protective Equipment (PPE) be used according to the appropriate regulations.
- Shall display the "Safety Regulations" and adhere to them closely.
- Shall ensure that all safety- and danger signs on and around the Lift are observed and followed!
- Shall follow the specified time intervals between the recommended inspection and maintenance procedures and tests.



- Shall use only spare parts that comply with the technical requirements specified by the manufacturer.
- Shall ensure that loose screws, nuts, and bolts are firmly tightened after maintenance.
- Shall not modify the Lift without written consent of Nussbaum.
- Shall ensure that these instructions are maintained and available to all personnel that install, use or maintain the lift. This document contains important information about installation, operation, and maintenance of the automotive Lift. Any changes to the installation and or location of the automotive Lift must be documented.

1.4 Lift operator responsibilities

- Shall read and understand all safety and warning instructions in the manual or affixed to the lift.
- Shall be trained to operate and use the HF 3S 8000 Lift for its designed use.
- Shall be familiar with accident prevention and basic labor safety regulations.
- Shall not allow unauthorized personnel to operate the Lift.

Information of warning

Pay close attention to the danger and important information symbols shown below. Carefully read all marked passages throughout this manual.



Danger! This sign indicates danger to life. Improper handling of the described operation may cause serious injury or death.

- Caution! This sign warns against possible damage to the automotive Lift or other material defects in case of improper handling.
- Attention! This sign indicates an important function or note.

1.5 Safety regulations



The Safety Regulations must be observed and strictly adhered to while working with the automotive Lift. Read the safety regulations and the ANSI/ALI ALOIM manual included with the lift documentation carefully before working with the Lift!

Important safety instructions – read all instructions

• The total weight of the lifted vehicle must not exceed 8000 pounds.

- The automotive Lift must be in its lowest position, and the Lift Carry Arms must be swung out before a vehicle can be driven into the Lift area.
- Total load must be distributed evenly on all arms.
- The Lift must not be installed in a hazardous location or in washing bays.
- The Lift must be checked by a service technician after initial installation and after repairs or changes have been made to the Lift.
- The operating and maintenance instructions must be followed while working with the Lift.
- Pre-check low clearance or specially equipped vehicles for ample clearance to avoid damage to the vehicle and/or Lift.
- Only trained personnel are to operate the Lift.
- No one is to stand within the working area (danger area) during vehicle lifting and lowering operations.
- No one is to occupy a vehicle during any phase of Lift operation.
- No one is to climb onto the automotive Lift when in a raised position.
- For unusual vehicles you may choose to instruct the user to contact Nussbaum for lifting advice.
- The main electrical switch must be switched off and locked out or tagged out according to OSHA Regulations before maintenance or repair work is performed on the Lift.
- The operator must continue to observe the vehicle and Lift throughout the lifting or lowering operation.
- Check the center of gravity of the vehicle if heavy parts, such as the engine are removed.
- If heavy parts such as the engine must be removed, the center of gravity will change. Secure the vehicle before removing parts to avoid the possibility of the vehicle becoming insecure.
- Read all instructions before operating lift.
- Care must be taken as burns may occur from touching hot parts.
- Do not operate the Lift with a damaged cord or if the Lift has been damaged until it has been examined by a qualified service person.
- To reduce the risk of fire, do not operate Lift in the vicinity of open containers of flammable liquids (gasoline).
- Adequate ventilation should be provided when working on operating internal combustion engines.
- Keep hair, loose clothing, fingers, and all parts of body away from moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Always wear safety glasses. Everyday eyeglasses only have impact resistant lenses, they are not safety glasses.
- The proper positioning of the carrier plate below the vehicle is to be checked again after the vehicle has been raised slightly.



- After each set down of the vehicle, check the lifting arm positions below the fixture points again and adjust as required.
- When disassembling heavy, consider any possible centre of mass shifts. The vehicle is to be appropriately secured using suitable materials (e.g. tensioning belts, beams, etc.) against falling.
- After design and maintenance on load bearing parts the lift must be inspected by a technical expert.
- Vehicles may only be attached at fixture points approved by the vehicle manufacturer.
- The entire lifting and lowering process is to be continuously observed.
- Initial access to the lift is only permitted after the main switch has been turned off and secured, and the operating lever is additionally secured against unauthorised use.

Save these instructions!

1.6 Safety devices

Nussbaum has designed several saftety features into each Lift to ensure safe and efficient operations under a variety of conditions. Warranties will be voided and dangerous working conditions exist if any of the listed devices are altered or disabled.

Over-pressure valve

Hydraulic system fuse against over-pressure.

Check valve

Secure the vehicle against unauthorised lowering.

- Main switch with curtain lock device Fuse to prevent unauthorised use.
- Command / downstream system with latch
 Secure against unauthorised lowering of the lift.
- Deadman controls

Lift movement stops when the operating lever is released.

Lifting arm block


Secures the lifting arm against horizontal movement in a lifted condition.



1.7 Safety labels affixed to lift

Warning Label pictographs used with permission of Automotive Lift Institute.







Read all labels and verify that all authorized users fully understand the meaning of each caution / warning / safety instruction. Do not remove or deface safety labels from the lift.

1.8 Protocols

Technical documentation contains important information for safe operation and for retaining functional safety of the lift.

- To verify lift set up, the assembly protocol form is to be completed, signed and sent to the manufacturer.
- Forms are available in this inspection book for use in verifying single, regular and extraordinary safety checks. Use the forms to document inspections and leave the completed forms in the inspection book.
- The lift master forms must record changes to the construction or changes to set up location.

1.9 Set up and test the lift

Safety relevant work on the lift and safety inspections may only be done by personnel specifically trained to carry it out. They are designated in general and in this documentation as technical experts and specialists (competent people).

- Technical experts are people (freelance expert engineers, TÜV specialists) that may inspect and assess due to their education and experience with lifts. They are knowledgeable in the appropriate work safety and accident prevention regulations.
- Specialists (competent people) are people who have sufficient knowledge and experience with lifts and have participated in a special factory training by the lifts manufacturer.



Set up protocol

After successful set up, complete this form fully, sign it, make a copy and send the original to the manufacturer within a week. The copy remains in the inspection book.

Nussbaum Automotive Solutions, LP 1932 Jordache Court Gastonia, NC 28052 Fax: 1-704-864-2476

Email: warranty@nussbaum-usa.com

Date Name, specialist Signature of specialist Service partner:			
checked for function and safety and put into operation. The set up was done by the operating company / specialist (score out the one that does not apply). After successful inspection of function and safety by a trained assembler, the lift is transferred without a trical connection (e.g. plug) to on-site power supply An on-site electrical connection between the lift the power supply is to be done by a qualified electrician (see details in the electrical plan). The operating company confirms proper lift set up, has read and will comply with all information contains this operating manual and inspection book, and will keep this document accessible to trained oper at all times. The specialist confirms proper lift set up, has read all information in this operating manual and inspections, and has transferred the documents to the operating company. Date Name, operating company and company stamp Operating company signal Signature of specialist Signature of specialist	The lift with serial number	was set up on (date) _	
The set up was done by the operating company / specialist (score out the one that does not apply). After successful inspection of function and safety by a trained assembler, the lift is transferred without or trical connection (e.g. plug) to on-site power supply An on-site electrical connection between the lift the power supply is to be done by a qualified electrician (see details in the electrical plan). The operating company confirms proper lift set up, has read and will comply with all information contain this operating manual and inspection book, and will keep this document accessible to trained oper at all times. The specialist confirms proper lift set up, has read all information in this operating manual and inspections, and has transferred the documents to the operating company. Date Name, operating company and company stamp Operating company signal Signature of specialist Service partner:	at (company name)	in (town, city)	
After successful inspection of function and safety by a trained assembler, the lift is transferred without trical connection (e.g. plug) to on-site power supply An on-site electrical connection between the lift the power supply is to be done by a qualified electrician (see details in the electrical plan). The operating company confirms proper lift set up, has read and will comply with all information contain this operating manual and inspection book, and will keep this document accessible to trained oper at all times. The specialist confirms proper lift set up, has read all information in this operating manual and inspection book, and has transferred the documents to the operating company. Date Name, operating company and company stamp Operating company signal Signature of specialist Service partner:	checked for function and sc	rfety and put into operation.	
in this operating manual and inspection book, and will keep this document accessible to trained oper at all times. The specialist confirms proper lift set up, has read all information in this operating manual and inspection book, and has transferred the documents to the operating company. Date Name, operating company and company stamp Operating company signal Date Name, specialist Signature of specialist Service partner:	After successful inspection o trical connection (e.g. plug)	f function and safety by a trained assembler, the to on-site power supply An on-site electrical co	e lift is transferred without elec- nnection between the lift and
book, and has transferred the documents to the operating company. Date	in this operating manual and		
Date Name, specialist Signature of specialist Service partner:			rating manual and inspection
Service partner:	 Date	Name, operating company and company stamp	Operating company signature
•	 Date	Name, specialist	Signature of specialist
orange and a second	Service partner:	Stamp	

10

*) See enclosed anchor manufacturer sheet



Transfer protocol

	_ in (town, city)
nd safety and put into c	ation.
	to handle the lift after it was set up by a trained assem- cialist).
empty lines must have	ored out)
 Name	
Name	Signature
 Name	Signature
Name	Signature
Name	Signature
 Name, specialist	Signature of specialist
Stamp	
	nd safety and put into operators of the (operators) were trained or or a contract partner (spetempty lines must have a scalar number of the contract partner of the contract p



2 System master sheet

2.1 Manufacturer

Otto Nussbaum GmbH & Co. KG Korker Straße 24 D-77694 Kehl-Bodersweier

2.2 Purpose

The lift is a lifting tool for raising vehicles with a total weight of 8000 lbs (3500 kg) in normal workshop operation.

Set up of the standard lift in explosion endangered workshops and humid spaces (e.g. washing halls) is prohibited.

Lift operation is done directly on the operating column (see Data sheet).

After construction and maintenance changes on load carrying parts the lift must be inspected afterwards by a specialist who approves the changes. If the set up location is changed, the lift must be checked again by a specialist and changed approved.

Otto lifting arms

570–1160 mm
995–1823 mm

2.3 Changes to the design / construction inspections by a technical expert are required expert signature).	on ed before recommissioning (date, type of change, technica
Name, address of technical expert	
Location, date	Technical expert signature
2.4 Changing the assembly location Inspections by a technical expert are require signature).	ed before recommissioning (date, type of change, specialist
Name, address of technical expert	

Location, date

Signature of Technical Expert of Safety inspections



3 Technical information

3.1 Technical data

Load carrying capacity:	HF 3S 8000=8000 lbs (3500 kg)
Loading a lifting arm:	A single load from only one lifting arm may not happen
HF 3S 8000:	Lift/lowering time: ap- prox. 20 s/seamless 0-max 14 s with 2.68 t
Standard operating voltage:	1 ~/N+PE, 230 V, 60 Hz
Motor capacity HF 3S 3000:	3 kW
Motor speed:	3450 rpm
Hydraulic pump:	1.5 GPM (≈ 5.6 l / min.
Lifting / lowering pressure:	190 bar / 120 bar
Pressure relief valve:	250 bar
Oil volume:	Approx. 10 litres (HLP32)
Noise level LpA:	≤70 dB
On-site connection:	1~/N+PE, 230 V, 60 Hz with 16 A fuses, slow, according to VDE regulations

3.2 Safety devices

• Over-pressure valve

Hydraulic system fuse against over-pressure.

Check valve

Secure the vehicle against unauthorised lowering.

- Main switch with curtain lock device
 Fuse to prevent unauthorised use.
- Two independent cylinder systems (each with a command, follow system)

Secure against unauthorized lowering of the lift.

• Deadman controls

Lift movement stops when the operating lever is released.

• Foot bumpers on the lifting arms
Secure against shear and crushing points in the foot area.


• Lifting arm block

Secures the lifting arm against horizontal movement in a lifted condition.

• Operating lever with curtain lock device Fuse to prevent unauthorised use.




3.3 Data sheet






Clearance around the lift





3.4 Hydraulic plan



0.1	BOSCH-USA	AC UNIT	K1	230SLNT02840 CYLINDER, COMMAND SIDE OPERATING SIDE
1.0 1.1	000JL21150-SB15	5 JL NT BLOCK CPL. PRESSURE RELIEF VALVE	K2	230SLNT02820 CYLINDER, COMMAND SIDE OPERATING SIDE
1.2	982602	SB LOWERING BRAKE 10L/MIN 1/4"	F1	230SLNT02830 CYLINDER, DOWNSTREAM SIDE
1.3 1.4 1.5 1.6	117874 974820 983700	CLOSING SCREW BALL VALVE CHECK VALVE LINE-BREAK SAFETY DEVICE	F2	230SLNT02850 CYLINDER, DOWNSTREAM SIDE



3.5 Electrical circuit diagram

Grounding according to local regulations

Before commissioning check whether the nominal motor current matches the motor protection relay. Check all terminal points for proper connection and that all contact screws are tight.

Before commissioning, check all wiring and controls for proper function. Do not permit commissioning from the unauthorised side.

These plans were generated on a CAD system. To keep plans to the current state, we ask that you request Nussbaum to make the changes.

These circuit diagrams are intellectual property. They may not be given to third parties or reproduced without our permission!

Rights to make changes are retained.

Circuit diagram and switch documents

Circuit diagrams were made to the best of our knowledge.


No guarantee is made for the accuracy of enclosed circuit diagrams and switch plans contained in this document. This is particularly relevant for switches that were completed by us according to third party plans. This was done by us from purchaser provided manufacturer documentation.

Functional test of switch systems


Circuit diagrams are not standard documents. When checking the control cabinet at the factory, field devices such as sensors, thermostats and motors cannot be included. For this reason, even with careful inspection, functional and switch errors cannot always be prevented.

Deficiencies are removed within the scope of guarantee during commissioning. During commissioning, if our services are not used, then no deficiency liability is accepted. Rework, including informing of circuit diagrams of switch systems not commissioned by us are therefore only done to an invoice according to our service terms and conditions. Costs for rework by third parties cannot be honoured.
















																																						<u> </u>	BI. O
NUSTÜCK2 16.11.2004	Artikelnummer	N° d'article N° d'article	000STR03564	9000STR03566	92323LU3U2B 9951969	9951971	996875	991032	990322	990322	995927	996883	996886	996881	999835	440630	11002U	118620	00MNG603160	992299	0015403	0015403	995577	7/2255												_	п +		0+1:17711140
matériel	Lieferant	Supplier Fournisseur		Hauss Elektronik GmbH	Jacob GmbH	Jacob GmbH			Marquardt GmbH	Omron	Omron	Lovato electric	Lovato electric	Lovato electric	Lovato electric	Lovato electric	Nissbain	Seehausen	Nussbaum	SICK	LAPP		Kabel Wachter GmbH & Co. KG	Kabel Wachter GmbH & Lo. KG												_	230V SPX	1	HF 3S 8000
Liste de m		Numéro de tope	000STR03564	PLATINE FÜR UNIVERSALSTEUERUNG	KARFI VFR CHARBIINING M16X1 5	KABELVERSCHRAUBUNG M32X1, 5	MEHRFACH DICHTUNG	R151/6.1050	1115, 0101	1113. U101 P71 F_060	67L -1A -T 24VDC	LPXB0	LPXB103	LPXC01	- P.XLIU	LP XHU1ZUn	DE KHIENDENET	GERRIESTECKER	HUBMAGNET	REFLEXIONS-LICHTSCHRANKE WL280	ÖLFLEX 150		PVC-STEUERLEITUNG FLEX	PVL-SIEUERLEIIUNG FLEX												_	HL-NT-K 1x		/0/0/00/00/00/00/00/00/00/00/00/00/00/0
Bill of materials	Bezeichnung	Descripption matériel	Platinen Halteblech Bl. 2x67,7x257 DX51 D+Z	Universalsteuerplatine V2	Schutzhaube für Elektrosteuerung Perfert Kahalverschraubung M16×1 5	Perfect Kabelverschraubung M32x1, 5	für 6 Leitungen (32H	+ .	MICEO DEFALESCHAILEE U + 3 Relaissonkel für Leisungsrelais 671		Drucktaste (D22mm) ohne Einlegeschild	Tastenplatte Start (-) (22mm)	Kontaktelement 1Ö (22mm)	Kontaktelement 15 (22mm)	berestigungsbasis (UZZmm)	VEHLIISLECKET LIOZ 3 NZI SCHWAFZ Klinkonmannetventil 2 UVNF 1 29 B :100% FN	-	Klinkenmagnetventil 24VDC,1,29 A ;100% ED	e WL280-523	LAPP Kabel-Halogenfrei Ölflex 150, 362,5	Ölflex 150,	Steuerleitung mit num. Adern (2 x1,0mm²)	Steuerleitung mit num. Hdern (2 x1,Umm²)												[Mussbaum Hebetechnik GmbH & Co.KG		
iste	Menge	Amount Qté.	1	T -	7	1 11	1	.	-			1	1	τ,					1	1	9	1	₩.	П													Datum 28.10.19		10.12.19
Stückli	Bauteilbenennung	Lomponent design. Désign. composant	1 1	11	10	11	11	-01	\$1	5.2 K1	± 1 ± 1 ± 1	S3	S3	S3	23	22.2	VK2 1	YK1. 1	YK1.1	hS-	WZ1	WM1	WYK1	WYR.2												2	Datum	Dearb.	Gepr.



POS	BMK	QIY.	DESIGNATION 1	TYPE NUMBER	MANUFACTURER	ITEM NUMBER
_	5	-	CIRCUIT BOARD HOLDING PANEL BL. 2X67.7X257 DX51 D+Z	000STA03564		000STA03564
7	17	_	UNIVERSAL CONTROLS CIRCUIT BOARD V2	CIRCUIT BOARD FOR UNIVERSAL CONTROLS	NB_UNVERSALCIRCUITBOARD	9000STA03566
က	17	-	Safety hood for electrical controls	SAFETY HOOD FOR ELECTRICAL CONTROLS	KERFT	9232SL03026
4	Ξ	7	PERFECT CABLE SCREW FITTING M16X1,5	CABLE SCREW FITTING M16X1,5	ЈАСОВ GMBH	9951969
2	17	-	PERFECT CABLE SCREW FITTING M32X1,5	CABLE SCREW FITTING M32X1,5	ЈАСОВ GMBH	9951971
9	Ξ	_	SEAL FOR 6 LINES (6MM) FOR	MULTIPLE SEALS	JACOB GMBH	996875
7	Ģ	_	MAIN SW. EMERGENCY STOP 3P 32A 7.5KW	A151/6.1050	MERZ GMBH	991032
∞	×	_	GROUND WIRE CLAMP D 2,5/6.P.ADO FAST-FAST	D 2,5/8.P.ADO	ENTRELEC	990185
6	S1	_	MICRO DEVICE SWITCH O + S	11.150.101	MARQUARDT GMBH	990322
10	\$2	_	MICRO DEVICE SWITCH O + S	11.150.101	MARQUARDI GMBH	990322
1	\subseteq	_	RELAY SOCKET FOR POWER RELAY G7L	P7LF-06D	OMRON	995926
12	\subseteq	_	POWER RELAY 24 VDC	G7L -1A -T 24VDC	OMRON	995927
13	83	_	PUSH BUTTON (D22 MM) WITHOUT INSERT SIGN	LPXB0	LOVATO ELECTRIC	996883
7	23	_	PUSH PLATE START (-) (22 MM)	LPXB103	LOVATO ELECTRIC	988966
15	23	_	CONTACT ELEMENT 1Ö (22MM)	LPXC01	LOVATO ELECTRIC	996881
16	23	_	CONTACT ELEMENT 1S (22MM)	LPXC10	LOVATO ELECTRIC	996885
17	23	_	FASTENING BASE (D22 MM)	LPXAU120'	LOVATO ELECTRIC	996884
18	YK2.1	_	VALVE PLUG C182 9 N21 BLACK	DEVICE PLUG	SEEHAUSEN	118620
19	YK2.1	_	LATCH SOLENOID VALVE 24 VDC, 1.29 A: 100% ED	LIFTING MAGNET	NUSSBAUM	00MNG603160
20	YK1.1	_	VALVE PLUG C182 9 N21 BLACK	DEVICE PLUG	SEEHAUSEN	118620
21	YK1.1	-	LATCH SOLENOID VALVE 24 VDC, 1.29 A: 100% ED	LIFTING MAGNET	NUSSBAUM	00MNG603160
22	-54	-	REFLECTION LIGHT CURTAIN WL280-5230	REFLECTION LIGHT CURTAIN WL280	SICK	992299
23	WZ1	W9	LAPP CABLE HALOGEN FREE, ÖLFLEX 150, 3G2.5	ÖLFLEX 150	LAPP	15403
24	WM1	\geq	LAPP CABLE HALOGEN FREE, ÖLFLEX 150, 3G2.5	ÖLFLEX 150	LAPP	15403
25	WYK1	\geq	CONTROL LINE WITH NUM. WIRES (2 X1,0MM²)	PVC CONTROL LINE FLEX	KABEL WÄCHTER GMBH & CO.KG 995577	3 995577
26	WYK2	10 M	CONTROL LINE WITH NUM. WIRES (2 X1,0MM²)	PVC CONTROL LINE FLEX	KABEL WÄCHTER GMBH & CO.KG 995577	3 995577



4 Installation

The installation of the Lift is performed by manufacturer trained technicians or by the manufacturer's distribution partner. The Lift owner may use their trained mechanics to install the Lift. The installation must be performed according to the following regulations:

- Use architectural plans, if available, to determine Lift location.
- Lift is intended for indoor installation only. Installation in an outdoor application is prohibited and will void the warranties of the product.
- Always consult a qualified person regarding local regulations for seismic requirements. The owner has

to consult a qualified person to address any local or state requirements (per the ALCTV standard: "a qualified person should be consulted to address any seismic loads and other local or state requirements")

- Do not install Lift in hazardous locations, pit or depression areas, or washing stalls.
- Concrete must have compression strength (see chapter 8).
- Mount on a foundation deeper than the local external frost line.
- Be sure to read the ANSI/ALI ALIS prior to installation.
- The installer has to return the instructional materials furnished with the lift back to the owner.

Shiping / parts list

POS	ITEM NAMES	ITEM CODES	QUANTITY	LOCATION
1	COLUMN MASTER WITH LIFTING		1	BOX
	CARRIAGE, CYLINDERS, POWER UNIT			
2	COLUMN SLAVE WITH LIFTING		1	BOX
	CARRIAGE, CYLINDERS			
3A	OTTO LIFTING ARM OPERATOR SIDE LONG	G 235HLNT08001	1	BOX
3B	OTTO LIFTING ARM OPPOSITE SIDE LONG	3235HLNT08002	1	BOX
3C	LIFTING ARM OPERATOR SIDE SHORT	235SL08051	1	BOX
3D	LIFTING ARM OPPOSITE SIDE SHORT	235SL08052	1	BOX
4	SET OF CABLE TIES FOR FIXING THE HOSE	S	1	BOX
5	CROSS BEAM		1	BOX
6	COVER PANEL	240SL09008	2	BOX
7	COVER WITH INDICATION OF WEIGHT	230SLH09047	2	BOX
8	MANUAL	975537	1	PLASTIC BAG

5 Operating manual



When handling the lift, it must absolutely comply with safety regulations. Carefully read the safety regulations in Section 1.5 before first operation!

5.1 Positioning the vehicle

Drive the vehicle onto the lift according to the following images, until the lifting arm receives it (figure A and B).




Figure. A) The lift column must be located between the steering wheel and the car door hinges!




Figure. B) Drive in the middle of the lift.

Swivel in the lifting arms and extend out to the desired position The adjustable receiving plates are to be placed at the pointed prescribed by the vehicle manufacturer.



Version with Mini-Max lifting arms



Figure 1: Position carrier plate below the fixture points approved by the vehicle manufacturer.



Figure 2: If required, place the carrier plate by pushing the lever at the fixture points.

Ensure that the ratchet is securely locked into the intended position. Otherwise the "Mini-Max" can sink to its lowest position.



Figure 3: To release the fixture plate, the rear lever must be pushed.

- The lifting arm block must be ratcheted in after the fixture point has been reached.
- After each set down of the vehicle, check the lifting arm positions below the fixture points again and adjust as required.
- Check that there are no people or objects in the hazardous area of the lift.

5.2 Lifting the vehicle

- Lift the vehicle until the wheels are off the ground.
 Push the operating lever forwards → "Lift" (see figure 4).
- If the wheels are not blocked, interrupt the lifting process and check for proper seating of the carrier plate. Similarly check whether the lifting arm blocks are ratcheted in. Otherwise, lower the lift and reposition the vehicle.
- After each set down of the vehicle, check the lifting arm positions below the fixture points again and adjust as required.
- Check that there are no people or objects in the hazardous area of the lift.
- Afterwards, lift the vehicle to the desired working height.



Ensure secure vehicle placement on the carrier plate, otherwise there is a danger of the vehicle dropping.

See to it that the lifting arm blocks are ratcheted in after the vehicle has been accepted.



Main switch


Figure 4: Operating unit




Operating lever Fig. similar



Lift:








5.3 Lift synchronization

- Uneven running of the lift is not possible in proper operation.
- For this, raise the lift to its uppermost end position. Push the operating lever for 2 more seconds. During this procedure the lift rails are equalised to each other as hydraulic oil flows to the tank as an overflow from the command cylinder via the downstream cylinder to the tank.
- Release the operating lever. The lift rails then lower some millimetres and thereby block the overflow opening of the cylinder.
- Both lift rails are now at the same height.

5.4 Lowering the vehicle

- Check that there are no people or objects in the hazardous area of the lift.
- Lower the vehicle to the desired working height or to its lowest position; pull the operating lever slowly → "Lower".
- For heavier vehicles, lift it slightly before lowering to prevent an "sticking" and any corresponding jolt during lowering.
- The lowering speed can be varied seamlessly.
- Once the lift is in the lowest position, push the lifting arms to the start position.



Lifting arm start position

Once the lift is in the lowest position, swing out the lifting arms to the start position.

• Move the vehicle out of the lift.

6 Behaviour in cases of error

Defective operational readiness of the lift may be due to a simple error. Check the system for the listed sources of error.

If the error cannot be removed after an inspection to the named causes, then inform customer service or your dealer.



Independent repairs to the lift, especially on the safety devices, as well as inspections and repairs to electrical systems are prohibited.

Work on electrical systems may only be done by electricians.

Problem: The lift cannot be raised

Possible causes:	Remedy:
No power supply present	Check power supply
The main switch is not switched on, or is defective	Check main switch
Operating lever defective	Check function
Defective fuse	Check fuses
Power line interrupted	Check power lines



Motor has overheated	Let motor cool (cooling time dependent on ambient temperature)
Motor defective	Do an emergency discharge (see Section 6.1)
Only 2 phases active	Do an on-site check with a qualified electrician
Insufficient hydraulic oil available	Refill new hydraulic oil


Problem: The lift cannot be lowered

Possible causes:	Remedy:
The lifting arm has moved onto an obstacle	Raise the lift and remove the obstacle.
Operating lever defective	Notify customer service Perform emergency dis- charge. Slowly pull lever

6.1 Emergency discharge



An emergency discharge is an access into the lift controls and may only be done by experienced specialists. The emergency discharge must be done in the following described sequence, otherwise it can lead to damage and hazard to life and limb. People may not stand in the hazardous area around the lift.



- 9 Operating lever
- 21 Emergency discharge valve





Preparation

- Loosen and remove the plastic part (T-piece) of the operating lever (9) at both screws on the side.
- Loosen and remove the stainless steel cover of the unit.
- After the lift has been set down into the latch then
 the lift must first be lifted (using a forklift, electrical
 pallet truck or similar) out of the latch so that it
 moves freely again. Then tie back the latch using,
 e.g. a cable tie.



Emergency discharge:

- Push on the black cap (21) of the valve and at the same time slowly pull the operating lever (9). The lowering procedure begins immediately. Lowering speed can be varied by the lever position.
- The lowering process must be continuously observed.
- Release the operating lever (9) to stop or if there is a danger.
- Lower the lift to the lowest position.
- Release the latch again (remove cable tie)
- Only operate the lift if it is in seamless condition from a safety point of view.
- If required, firstly inform customer service.

6.2 Moving onto an obstacle

If the lifting rails or lifting arms move onto an obstacle due to operator inattention, the lift stops in place. To remove the object, raise the lift to a height where the object can be removed.

7 Maintenance and care of the lift

Before maintenance, do all preparation work so there is no danger to life or limb or object damage during maintenance and repair work.

Value is placed on long lifetimes and safety in the development and production of Nussbaum products. To guarantee the safety of the operator, product reliability, low running costs, keep the warranty and also the long-lifetime of the product, proper set up and operation is just as important as regular maintenance and sufficient care.

Our platforms fulfil or exceed all safety standards of the countries we supply to. For example, European regulations require a service by qualified experts every 12 months of work of the platform. To guarantee the largest possible availability and functional capacity of the lift system, ensure the list of any cleaning, care and maintenance work is done.

After first commissioning the lift is to be serviced at regular intervals of a maximum of one year by an authorized person according to the following plan. For intensive operation and higher degree of contamination shorten the service interval.

The complete function of the lift is to be observed during daily use. Customer service must be informed of any malfunctions.



7.1 Maintenance plan

Before beginning service, disconnect from power. The work area around the lift is to be secured against unauthorised use.

		₹		TE.	I M	X
Visual inspection	Spray	Oil	Lubricate	Clean with compressed air	Clean	Inspect

Ti	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
As required			Lift owner / employer	The lift cylinder can sweat and small oil droplets can form on the base plate, this is however, not a leak.
Daily	9 365 x / 12 3 8 7 6 5		Lift owner / employer	Model and information signs, labels, brief operating instructions, safety stickers and warning information are to be cleaned and exchanged if damaged.
Daily	9 365 x / 12 3 8 7 6 5		Lift owner / employer	Check the foot bumper for condition and function. Exchange if damaged.
Daily	9 365 x / 12 3 8 7 6 5		Lift owner / employer	The rubber acceptance plate is to be checked for wear and replaced if necessary.
Every 3 months	9 4 x / 12 3 8 7 6 5		Lift owner / employer	Check the tracks and the lift rail equalization parts for wear. After cleaning, grease with multi-purpose grease. We exclusively recommend that MO-2 high performance lubricating grease is used. (available for purchase directly from Oest).
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Check the lifting arm block and gear for wear. Exchange if there is visible damage.



Ti	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Lifting arm booms, lifting arm bolts, carrier plate threaded bolts are to be checked for ease of running. If required, lightly grease with multi-purpose grease. Do not over-lubricate.
Every 3 months	9 4 x / 12 3 8 7 6 5		Lift owner / employer	Version with MINI-MAX lifting arm 1. Blow out and spray bolts. Check the rollers for wear. 2. Check the locking screws (this is only screwed in lightly and is then glued (Loctite)). Screws may not be completely tightened otherwise the ease of running of the Mini-Max mechanism is no longer guaranteed. 3. Clean and spray this frictional surface. "Penetrating oil" similar to Top 2000 from Autol. 4. Check the safety plate for damage and exchange if required.
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Check all fastening screws and anchors with a torque wrench. Fastening class 8.8 0.08* 0.12** 0.14*** M8 17.9 23.1 25.3 M10 36 46 51 M12 61 80 87 M16 147 194 214 M20 297 391 430 M24 512 675 743 Fastening class 10.9 0.08* 0.12** 0.14*** M8 26.2 34 37.2 M10 53 68 75 M12 90 117 128 M16 216 285 314 M20 423 557 615 M24 730 960 1060 * Lubricated slide friction number 0.8 MoS2 ** Lightly oiled slide friction number 0.12 *** Ensured slide friction number 0.14 screw with micro-encap-sulated plastic



Т	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	All weld seams must have a visual inspection. Stop the system and contact the manufacturer if there are cracks or breaks in weld seams of the lift.
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Check electrical components for function and condition. • Plug. • Operating lever with button switch. • During assembly and maintenance always check the condition of electrical lines. All cables and lines must be secured so they cannot be crushed, kinked or contact any moving assembly.
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Optional energy set:
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	 Check the paint: Check the powder coating and improve if required. Damage by external influences is to be treated immediately after detection. If these points are not treated, infiltration of deposits of all kinds can cause wide-ranging and permanent damage. These points are to be lightly sanded (120 grit), cleaned and degreased. Afterwards, rework with a suitable touch up paint (note the RAL No.). Check galvanised surfaces, touch up as needed. White rust is fostered by permanent humidity, poor ventilation. The affected areas can be treated by using a sanding cloth (A 280 grit). If required, the parts are to be treated with a suitable, resistant material (paint etc.). Check the RAL colour selection. Rust is brought out by mechanical damage, wear, aggressive deposits (de-icing salt, leaking operating fluids) cleaning that is not done or incomplete. The affected areas can be treated by using a sanding cloth (A 280 grit). If required, post-treat the areas with a resistant material (paint etc.).



Ti	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		Trained service personnel	According to manufacturer instructions, the hydraulic oil should be changed every two years in normal operations. Various environmental influences e.g. location, temperature swings, intensive operation etc, can have an influence on the quality of the hydraulic oil. For this reason, the oil must be checked during annual safety inspections and maintenance. The oil is used if it has a milky colour or if the hydraulic oil smells unpleasantly. To change oil, lower the lift is to its lowest position then suction the oil out of the oil container and replace the contents. The manufacturer recommends high-quality clean hydraulic oil. The required oil volume and type is to be taken from the technical data. After filling (18), the hydraulic oil must be between the upper and lower marking on the oil dipstick, or approx. 2 cm below the oil filling opening. Dispose of the old oil according to regulations to the intended location (district offices, environmental protection office or commercial regulatory office has the obligation to disclose about disposal points).



Т	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		Trained ser- vice personnel	Storage and duration of use Excerpt from DIN20066:2002-10 • For permitted loading, hoses undergo a natural change. This limits the duration of use. • Improper storage, mechanical damage and unpermitted loads are the most frequent cause of breakdowns. • The duration of use of a hose line including any storage time should not exceed six years. Hose lines are to be replaced if/when, • Damage to the outer coating up to the insert (chafe marks, cuts, cracks). • The outer coating becomes brittle (crack formation). • Deformation from the natural shape in the depressurised and pressurised conditions. • Leakage. • Damage or deformation of the mounting fixture. • Meandering of the mounting fixture. • The lifetime has been exceeded. Repair of the hose line using the implemented hose / mounting fixture is not permitted. Extending the replacement intervals given in the guideline is possible if the inspection for safe-work condition is done in adjusted, shortened time frames, if required and by competent personnel. If there is an extension of the replacement interval, no situation may occur which could result in injury of employees or other personnel.
Annually	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		Trained service personnel	Excerpt from BGR237: Specifications for the hydraulic hose lines. Normal specification: Recommended exchange intervals: 6 years (operation duration including max. 2 years storage time). Increased demands e.g. by • Increased usage times e.g. multi-shift, short cycle times and pressure impulses. • Increased exterior and interior (due to media) influences which significantly reduce the lifetime of the hose lines. Recommended exchange intervals: 6 years (operation duration including max. 2 years storage time).



7.2 Cleaning the lift

A regular and expert clean helps retain the value of the lift.

Additionally, it can also be a pre-requisite for the preservation of guarantee claims for any eventual corrosion damage.

The best protection for the lift is regular removal of contaminants of any kind.

This includes above all:

- De-icing salt
- Sand, pebbles, earth
- Industrial dust of all types
- Water, also in connection with other environmental influences
- Aggressive deposits of all types
- Permanent humidity due to insufficient ventilation

The frequency of lift cleaning depends, among other things on the frequency of use, of lift handling, of workshop cleanliness, and the location of the lift. Furthermore, the degree of contamination depends on the time of year, the weather conditions and workshop ventilation. Under adverse circumstances, weekly lift cleaning might be required, however a monthly cleaning may be sufficient.

Do not use and aggressive and abrasive materials for cleaning, rather use mild cleaners, e.g. a commercially available detergent and lukewarm water.

- For cleaning, do not use high pressure washers (e.g. steam cleaners).
- Carefully remove all contamination with a sponge, or if required with a brush.
- Make sure that there is no residue of the cleaner on the lift
- Dry the lift with a cloth and spray it with a spray wax or oil.
- Moving parts (bolts, bearing zones) are to be lubricated or oiled according to instructions.
- When cleaning the workshop floor ensure that no aggressive cleaning materials come into contact with lift surfaces. Permanent contact with any kind of liquid is prohibited.

7.3 Checking the stability of the lift

Retighten nuts of the approved fastening anchors to the torques specified by the manufacturer using a pre-set torque wrench (Torque details are found on the data sheet of the corresponding anchor manufacturer).

8 Assembly and commissioning

8.1 Set up guidelines

- Lift set up is done by trained manufacturer personnel or a contract partner. Set up is to be done according to the assembly instructions.
- A standard lift may not be set up in explosion endangered spaces or wash halls.
- Before setting up, ensure or make a sufficient foundation.
- A level set up space is to be done in all cases, where open air and enclosed foundations where frost is expected, must have a frost-depth thickness.
- An on-site standard electrical connection of $1 \sim /N + PE$, 230 V, 60 Hz is to be provided. The supply is to be secured according to VDE0100 with 16 ampere fuses. The minimum line cross-section is 2.5 mm².
- The lines can be fed through the cross-beams. In all cases, prevent kinks or tensional loads on the lines
- After successful lift installation and before first commissioning, the operating company must have the lift grounding conductors inspected onsite according to IEC regulation (60364-6-61). An insulation resistance test is also recommended.

8.1.1 Set up and anchoring the lift

On-site provision of suitable auxiliary materials (e.g. forklifts, crane, etc.) are to be made available for unloading the lift and for assembly.

Before setting up the lift, the operating company must ensure or make a sufficient foundation. For this, a normal reinforced concrete floor with a value of a min. C20/25 is required. The minimum foundation thickness (without screed and tiles) is to be taken from the foundation plan in this document.

In our plans, we inform of the minimum specifications for the foundation, however local conditions (e.g. underground, floor quality, etc.) are outside of our responsibility. In special cases, the design of the installation location must be individually specified by planning architects and statics experts. Open air foundations must be made to frost depth.

The operating company of the lift is solely responsible for the set up location.

If the lift is to be assembled on an existing concrete floor, cement quality and strength are to be checked beforehand. In case of doubt, make a test bore and insert an anchor. Then, tighten the anchor to the manufacturer recommended torque. After inspection within the anchor zone of influence (200 mm diameter) (see technical data sheet of the anchor manufacturer), if there is visible



damage (hairline cracks, cracks or similar), or if the required torque cannot be applied then the set up location is unsuitable.



Figure 21: General assembly view without riser extension

- 1 Cross-beam
 - Operating column 6
- 3 Long lifting arm
- 4 Operating unit
- 5 Riser
- 6 Counter column
- 7 Short lifting arm
- A foundation must be made according to the "Foundation plan" sheet regulations. Also a level, set up surface must be ensured for the lift so there is continuous contact between the lift and the concrete floor.




Figure 22: Anchoring

- 1 Column
- 2 Base plate
- 3 Safety anchor
- To reach a higher level of protection against humidity from the workshop floor, a thin PE foil should be put between the workshop floor and column

- base plate before anchors are placed. Also, the gap between the base plate and workshop floor should be silicone sprayed after anchoring.
- Lift the cross-beam that is fastened to a column and fasten to the opposite side. Hydraulic lines are marked in colours thereby making them easy to connect.
- Holes for floor anchoring are to be placed through the holes in the base plates.
 - Clean the bore holes by blowing them out with air. Insert safety anchors into the holes.


The manufacturer recommends e.g. Hilt injection anchors or similar anchors from other manufacturers, with approval and in compliance with their specifications.

Before anchoring the lift, check whether the concrete is of quality C20/25 up to the finishing level of the completed floor. In this case, determine the anchor length from the "Selection of anchor length without floor covering (in appendix) data sheet. If there is a floor covering (tiles, screed) on the weight bearing concrete, the thickness of this covering must be determined. Afterwards, then determine the anchor length from the "Selection of anchor length without floor covering (in appendix) data sheet.

- Position and align the lift and lift columns using a bubble level.
- The base plates are also to be supported with suitable underlays (thin metal strips) to ensure precise vertical set up and contact between the base plate and the floor.
- Tighten the anchors using a torque wrench.
- Each anchor must be able to be tightened to the torque specified by the manufacturer. Safe operation of the lift is not guaranteed with a lower torque.
- If an anchor is tightened to the specified torque, then the domed washer lays flat on the base plate.
 Secure anchor connection is then guaranteed.



8.1.2 Lift assembly with riser extension



1. Riser extension is set on the existing riser. The open side faces inwards.



2. Set to the desired height (from 100 mm to 900 mm in 100 mm steps) depending on the ceiling height. Guide the 4 hydraulic lines (fastened to the operating column) upwards out of the riser.



3. Fasten the cover.




4. After setting up the lifting columns, lift the cross-connection fastened to the operating column upwards and fasten to the opposite side. The hydraulic lines are placed in the cross-connection.

- 5. Guide the lines from above into the riser of the opposite side and connect to the colour marked positions.
- 6. Fasten the extension using the long screws after the tensioning plate (A) has been placed.



8.1.3 Retrofitting the riser extension



1. The optional riser extensions are delivered in a box. Have other supplied parts at hand: Hoses, covers, plates, extensions, press panels, screws.



2. Riser extension is set on the existing riser. The open side faces inwards.





3. Set to the desired height (from 100 mm to 900 mm in 100 mm steps) depending on the ceiling height.



4. Fasten the extension using the long screws after the tensioning plate (A) has been placed.



5. Fasten the cover.



6. Remove existing hydraulic lines. Do not remove colour markings.



7. Loosen and turn the T-piece and bracket visible in the figure.



Exchange the supplied hydraulic hoses

1. Place yellow and white on the top of the operating column.



2. Attach red directly to the unit.



3. Connect blue to K1 of the operating column.



4. Cut the cover panel to length and mount.





8.1.4 First filling with hydraulic oil


When filling the hydraulic system, identify already filled cylinders (with the sticker "first filling" on the system) and unfilled cylinders (no sticker on the system). Lifts with this sticker already have hydraulic oil in the hydraulic cylinders.



First filling with sticker

Required oil volume: 9 litres (HLP 32) for system. Lifts with this sticker already have hydraulic oil in the hydraulic cylinders and hoses.

After setting up the electrical connection to the lift, the hydraulic system can be filled.



9 Operating lever10 2x Allen key operating lever11 Oil filling opening

- Loosen and remove the plastic part of the operating lever (9) of both Allen screws (10).
- Loosen and remove the unit cover.
- Unscrew the oil filling opening (11).
- Fill 9 litre hydraulic oil (HLP 32).
- Raise the lift approx. 1 m by pushing the operating lever (9). The lift rails can be lifted at different times!
- Hang in the lifting arms and secure them.

- Push the operating lever forwards and raise the lift to its uppermost end position.
- Push and hold the operating lever for another 60 seconds so air can escape from the system and the overflow procedure equalises the lift to each other.
- For first commissioning, it is normal to have a different start up and a large "shaking" in the uppermost position. Air trapped in the system must be completely removed first.
- Afterwards lower the lift to its lowest position. Pull the operating lever (9) and hold it until the lifting arm is completely lowered.
- The oil level should be approx. 30–40 mm below the oil fill opening. Do not fill the oil tank up to the upper edge, as otherwise during lowering the oil return line can pull oil out of the line and afterwards result in a very slow lifting at the upper range.
- After commissioning, the sticker (first filling) can be removed.

First filling without sticker.

Required oil volume: 13 litres (HLP 32) for system, hoses and cylinders.

- After setting up the electrical connection to the lift, the hydraulic system can be filled.
- Loosen and remove the plastic part of the operating lever (9) of both Allen screws (10).
- Loosen and remove the unit cover.
- Unscrew the oil filling opening (11).
- Fill hydraulic oil: 9 litre (HLP 32).
- Raise the lift approx. 1 m by pushing the operating lever (9). The lift rails can be lifted at different times!
- Hang in the lifting arms and provide with safety rings.
- Push the operating lever (9) forwards and raise the lift to its uppermost end position.
- Now fill the oil tank with hydraulic oil: 4 litre (HLP 32)!
- Afterwards hold the operating lever another 60 seconds so air can escape from the system and the lift rails can be equalised by the overflow procedure.
- For first commissioning, it is normal to have a different start up and a large "shaking" in the uppermost position. Air trapped in the system must be completely removed first.
- Afterwards lower the lift to its lowest position. Pull the operating lever (9) and hold it until the lifting



arm is completely lowered.

The oil level should be approx. 30–40 mm below the oil fill opening. Do not fill the oil tank up to the upper edge, as otherwise during lowering the oil return line can pull oil out of the line and afterwards result in a very slow lifting at the upper range.

8.2 Lifting arm assembly

Hang in the standard lifting arm and then place an acid-free multi-purpose grease into the joint bolts in each case from above into the hole and then insert the enclosed locking ring.



The lifting arm bolts must be secured on both sides as otherwise a reliable connection is not given between the lift rails and lifting arm.

8.3 Lifting arm alignment

After assembly of the lift, the lifting arm may be placed at the lowest position and become difficult to move. There is the option of setting the set screw so that the lifting arms can be moved more easily.




Position of the setting screws

8.3.1 Control of the self-locking nuts

After the assembly, the self-locking nuts have to be checked. The threads of the piston rod must protrude from the nuts (see drawing).



Self-locking nuts



8.4 Commissioning

Before commissioning, a single safety inspection must be done (use the Single Safety Inspection form).

If the lift set up is done by a specialist (factory trained assembler) then he can also do the safety inspection. If the set up is done by the operating company then a specialist must be tasked with the safety inspection.

The specialist confirms seamless operation of the lift on the set up protocol for single safety inspection and releases the lift for use.

After commissioning please complete the assembly protocol and send to the manufacturer immediately.

8.5 Changing the assembly location


To change the assembly location the pre-conditions must be met according to the assembly guidelines. The location change is to be done according to the following sequence:




- Move the lift rails to about half height.
- Remove the lifting arm (remove the safety ring of the lifting arm pin, pull out the lifting arm pin and remove the lifting arm).
- Disconnect electrical supply lines to the lift from mains power.
- Remove hydraulic lines above on the opposite side and seal them off with blind stoppers.
- Only loosen cross beams on one side and fold them under along with the hydraulic lines.
- Securely fix the beam to the columns.
- Suction off hydraulic oil.
- Loosen the anchor fastenings.
- Carefully transport the lift column using appropriate auxiliary means (e.g. crane, forklift, etc) to the new assembly location.
- Assemble the lift according to the procedure during assembly and anchoring before first commissioning.
- Use new anchors. The old anchors are no longer fit for purpose.



8.5.1 Fischer anchor





subject to alterations!

fischer anchor


POWER LIFT HF 3S 3000 POWER LIFT HF 3S 3500 POWER LIFT HF 3S 4000

typ of dowel		FH 18 x 100/100 B Order No. 972230
drilling depth (mm)	† _d	230
min.anchorage depth (mm)	hef	100
thickness of concrete (mm)	С	see current foundation-diagram drawing
diameter of bore (mm)	d₀	18
thickness of the lift-piece (mm)	† _{fix}	0-100
turning moment (Nm)	Mo	80
Total length (mm)	I	230
Thread	М	M12
piece number	а	4
	b	8
	С	10
	d	12
	e	16
	f	20
	g	14

It is possible to use equivalent safety-dowels (with license) of other manufacturer but observe their regulations.



8.5.2 Hilti injection anchor



subject to alterations!

Hilti injection anchor

POWER LIFT HF 3S 3000^d POWER LIFT HF 3S 3500^d POWER LIFT HF 3S 4000^e

concrete floor		without floor pavement (tiles)
type of dowel		HIT-V-5.8 M12x150 Art.Nr.387061
drilling depth (mm)	h _o	108
min.anchorage depth (mm)	h _{ef}	108
thickness of concrete (mm)	H _{min}	min.138
diameter of bore (mm)	d ₀	14
thickness of the lift-piece (mm)	† _{fix}	max.19
turníng moment (Nm)	Tinst	40
Total length (mm)	I	150
Thread	М	12
piece number	а	4
	b	8
	С	10
	d	12
	е	14
	f	16
	g	28

Observe necessarily the installation description of the dowel manufacturer. Use longer dowels with version with floor pavement and tiles.

It is possible to use equivalent injections dowels (with license) of other manufacturer but observe their regulations.



9 Safety inspection

The safety inspection is required to guarantee operational safety of the lift. It is to be done.

- 1. before first commissioning after setting up the lift Use the "single safety inspection" form
- After first commissioning, check regularly at least once per year.
 Use the "regular safety inspection" form.
- 3. After changes to the lift construction.

 Use the "extraordinary safety inspection" form.
- Single and regular safety inspections must be done by a specialist. It is recommended to do maintenance at the same time.
- After a change in construction (for example changing the load carrying capacity or changing the lifting height) and after significant maintenance on load carrying parts (e.g. welding work), inspection by a technical expert is required (extraordinary safety inspection).

This inspection book contains forms with a printed inspection plan for safety inspections. Please use the appropriate form, record the condition of the inspected lift and leave the completed form in this inspection book.



9.1 Single safety inspection before commissioning

Test step	OK	Defect	Reinspect	Remarks
		missing		
Model plate	🖳	🖳	🛚	
Brief operating instructions on the column .	🗆	🗆	🗆	
Load capacity details on the lift	🗆	🗆	🗆	
Detailed operating manual	🗆	🗆	🗆	
Condition, function operating lever and butto	n 🗆	🗆	🗆	
Label "LIFT, LOWER"	🗆	🗆	🗆	
Condition, lockable main switch	🗆	🗆	🗆	
Condition, rubber plate	🗆	🗆	🗆	
Securing the lifting arm bolts				
Secure the receiving plate (not unscrewable	∍) □	🗆	🗆	
Condition, function carrier plate	🗆	🗆	🗆	
Condition, function foot bumper (optional)	🗆	🗆	🗆	
Condition, function safety catch	🗆	🗆	🗆	
Condition sliding part lift rails			П	
Paint condition	🗆	🗆	🗆	
Load bearing construction (deformations, cracks) 🗆	🗆	🗆	
Fastening screw torque	🗆	🗆	🗆	
Nuts Cylinder mounting set correctly	🗆	🗆	🗆	
Nuts Cylinder Mount: Check Sealing Wax	🗆	🗆	🗆	
Fastening anchor torque				
Condition, function lifting arm block	🗆	🗆	🗆	
Condition, function lifting arm movement	🗆	🗆	🗆	
Condition, safety plate on Mini-Max	🗆	🗆	🗆	
Condition, function of Mini-Max lifting arm.	🗆	🗆	🗆 💳	
Condition of cross-beam	П	П		
Cylinder condition	🗆	🗆	🗆 🗀	
Condition wiper cylinder	🗆	🗆	🗆	
Condition of covers	🗆	🗆	🗆 🗀	
Condition, function riser extension	🗆	🗆		
Condition of concrete floor (cracks)				
Condition electrical lines	🗆	🗆	🗆 🗀	
Condition, hydraulic lines + screw fittings	🗆	🗆		
Condition, hydraulic unit	🗆	🗆		
Functional test lift with vehicle				
Functional test "overflows"	🗆	🗆		
Stability of lift				
General condition of lift	🗆	🗆		
*) Place a checkmark in the relevant, if a retest is req	uired then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
	ontinue	d operation o	questionable, rei	nspection required
•			sible,removedefe	
			nue to operate	
	3 401101	2.10.00, 0011111		
Signature of specialist Operc	nting com	pany signature		
If requested to take care of deficiencies	- '	-		
. Deficiency removed on:				
			Opera	ing company signature



$\stackrel{\circ}{\mathbb{I}}$ Copy, complete and leave in the ins	spection boo	k Serial num	nber:	
Test step	OK	Defect missing	Reinspect	Remarks
Model plate	🗆			
Brief operating instructions on the colu	mn □	🗆		
Load capacity details on the lift				
Detailed operating manual		П		
Condition, function operating lever and b	button \square	П	П	
Label "LIFT, LOWER"				
Condition, lockable main switch				
Condition, rubber plate				
Securing the lifting arm bolts				
Secure the receiving plate (not unscrev	vable) 🗆			
Condition, function carrier plate				
Condition, function foot bumper (optic		⊔ □		
Condition, function safety catch	лы, <u>—</u>			
Condition sliding part lift rails				
Paint condition	□	⊔ □		
Load bearing construction (deformations, c		⊔ □		
Fastening screw torque	паску <u>п</u>	⊔ □		
Nuts Cylinder mounting set correctly	□	⊔ ⊓		
Nuts Cylinder Mount: Check Sealing W		⊔ ⊓		
Fastening anchor torque	uх	□		
Condition, function lifting arm block		□		
Condition, function lifting arm movements				
Condition, safety plate on Mini-Max				
Condition, function of Mini-Max lifting of	□	□		
Condition of cross boom				
Condition of cross-beam		⊔		
Condition winer cylinder				
Condition wiper cylinder Condition of covers				
Condition, function riser extension				
Condition of concrete floor (cracks)				
Condition electrical lines				
Condition by drawling lines I serow fittings				
Condition, hydraulic lines + screw fittings				
Condition, hydraulic unit				
Functional test lift with vehicle				
Functional test "overflows"				
Stability of lift	⊔	∐		
*) Place a checkmark in the relevant, if a retest	is required then	check it again!	⊔	
Safety inspection done on:				
Performed by company:				
Name address of specialists				
Name, address of specialist:	Continue	d aparation a	w.cotionololo roi	nana atian rasuirad
				nspection required
_		•	sible,removedefe	ecisby
I	□ No deficie	encies, confir	nue to operate	
Signature of specialist (Operating comp	pany signature		
If requested to take care of deficiencie	es .			
Deficiency removed on:				
(Use a new form for reinspection!)			Opera:	ting company signature
(



Condition, function operating lever and button	$\stackrel{\circ}{\mathbb{I}}$ Copy, complete and leave in the in:	spection boo	k Serial num	nber:	
Brief operating instructions on the ecolumn			missing	•	
Load capacity details on the lift	Model plate	🗆	🗆	🗆	
Detailed operating manual.	Brief operating instructions on the colu	mn 🗆	🗆	🗆	
Condition, function operating lever and button	Load capacity details on the lift	🗆	🗆	🗆	
Label "UFT, LOWER"	Detailed operating manual	🗆	🗆	🗆	
Condition, lockable main switch	Condition, function operating lever and I	outton \square	🗆	🗆	
Condition, Nuction (Iffing arm block	Label "LIFT, LOWER"	🗆	🗆	🗆	
Securing the lifting arm bolts	Condition, lockable main switch	🗆	🗆	🗆	
Secure the receiving plate (not unscrewable)	Condition, rubber plate	🗆	🗆	🗆	
Condition, function carrier plate	Securing the lifting arm bolts	🗆	🗆	🗆	
Condition, function foot bumper (optional)					
Condition, function safety catch	Condition, function carrier plate	🗆	🗆	🗆	
Condition, function safety catch	Condition, function foot bumper (optic	onal) 🗆	🗆	🗆	
Paint condition	Condition, function safety catch	🗆	🗆	🗆	
Load bearing construction (deformations, cracks)	Condition sliding part lift rails	🗆	🗆	🗆	
Fastening screw forque	Paint condition	🗆	🗆	🗆	
Nuts Cylinder mounting set correctly					
Nuts Cylinder Mount: Check Sealing Wax	Fastening screw torque	🗆	🗆	🗆	
Fastening anchor torque					
Condition, function lifting arm block	Nuts Cylinder Mount: Check Sealing W	ax 🗆	🗆	🗆	
Condition, function lifting arm movement					
Condition, function of Mini-Max lifting arm					
Condition, function of Mini-Max lifting arm	Condition, function lifting arm moveme	ent 🗆	🗆	🗆	
Condition of cross-beam					
Cylinder condition	Condition, function of Mini-Max lifting of	arm 🗆	🗆	🗆	
Condition wiper cylinder	Condition of cross-beam	🗆	🗆	🗆	
Condition of covers	Cylinder condition	🗆	🗆	🗆	
Condition, function riser extension	Condition wiper cylinder	🗆	🗆	🗆	
Condition of concrete floor (cracks)	Condition of covers	🗆	🗆	🗆	
Condition, hydraulic lines + screw fittings	Condition, function riser extension	🗆	🗆	🗆	
Condition, hydraulic lines + screw fittings	Condition of concrete floor (cracks)	🗆	🗆	🗆	
Condition, hydraulic unit	Condition electrical lines	🗆	🗆	🗆	
Functional test lift with vehicle	Condition, hydraulic lines + screw fittings	🗆	🗆	🗆	
Functional test "overflows"	Condition, hydraulic unit	🗆	🗆	🗆	
Stability of lift	Functional test lift with vehicle	🗆	🗆	🗆	
General condition of lift					
*) Place a checkmark in the relevant, if a retest is required then check it again! Safety inspection done on: Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature					
Safety inspection done on: Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	General condition of lift		🗆	🗆	
Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continuedoperationpossible, removed efects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	*) Place a checkmark in the relevant, if a retest	is required then	check it again!		
Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continuedoperationpossible, removed efects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	Safety inspection done on:				
Result of inspection: Continued operation questionable, reinspection required Continuedoperation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	Performed by company:				
Result of inspection: Continued operation questionable, reinspection required Continuedoperation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	Name address of specialists				
Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature		Continue	d operation o	ruestionable rei	nspection required
Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	kesun or inspection.				
Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature					ecisby
If requested to take care of deficiencies Deficiency removed on: Operating company signature		LI NO delicie	encies, coniir	ive to operate	
Deficiency removed on: Operating company signature	Signature of specialist	Operating comp	pany signature		
Operating company signature	If requested to take care of deficiencies	es			
	Deficiency removed on:			Operation	ting company signature
	(Use a new form for reinspection!)			Opera	ing company signature

OPI-POWER LIFT HF 3S 8000-V1.0-EN



$\overset{\circ}{\mathbb{D}}$ Copy, complete and leave in the insp	ection boo	k Serial num	nber:	
Test step	OK	Defect missing	Reinspect	Remarks
Model plate	🗆	🗆	🗆	
Brief operating instructions on the colum				
Load capacity details on the lift	🗆	🗆	🗆	
Detailed operating manual	🗆	🗆	🗆	
Condition, function operating lever and bu	utton □	🗆	🗆	
Label "LIFT, LOWER"	🗆	🗆	🗆	
Condition, lockable main switch	🗆	🗆	🗆	
Condition, rubber plate	🗆	🗆		
Securing the lifting arm bolts	🗆	🗆	🗆 💳	
Secure the receiving plate (not unscrewo	able) 🗆	🗆	🗆 💳	
Condition, function carrier plate	🗆	🗆		
Condition, function foot bumper (option				
Condition, function safety catch				
Condition sliding part lift rails		□		
Condition		□		
Paint condition(deformations, era	L			
Load bearing construction (deformations, cro	icks) \square			
Fastening screw torque	∐	∐	∐	
Nuts Cylinder mounting set correctly	∐	∐	∐	
Nuts Cylinder Mount: Check Sealing Wa	x 🗆	🗆	🗆	
Fastening anchor torque	🗆	🗆	🗆	
Condition, function lifting arm block	🗆	🗆	🗆	
Condition, function lifting arm movemer	nt 🗆	🗆	🗆	
Condition, safety plate on Mini-Max	🗆	🗆	🗆	
Condition, function of Mini-Max lifting ar	m 🗆	🗆	🗆 💳	
Condition of cross-beam	🗆		П	
Cylinder condition		 П		
Condition wiper cylinder				
Condition of covers				
Condition, function riser extension		□		
Condition of concrete floor (cracks)		⊔		
Condition of concrete 11001 (Clacks)		🗀		
Condition electrical lines	📙	∐		
Condition, hydraulic lines + screw fittings	∐	∐		
Condition, hydraulic unit	∐	∐		
Functional test lift with vehicle				
Functional test "overflows"	🗆	🗆	🗆	
Stability of lift				
General condition of lift *) Place a checkmark in the relevant, if a retest is			🗆	
Safety inspection done on:	·	-		
Performed by company:				
Name, address of specialist:		1 11		
Result of inspection: \Box		•	•	nspection required
			sible,removedete nue to operate	ectsby
Signature of specialist O ₁	perating comp	pany signature		
If requested to take care of deficiencies				
Deficiency removed on:				#:
(Use a new form for reinspection)			Opera	ting company signature

46



\prod Copy, complete and leave in the in	spection boo	k Serial num	nber:	
Test step	OK	Defect missing	Reinspect	
Model plate	🗆	🗆	🗆	
Brief operating instructions on the colu	mn 🗆	🗆	🗆	
Load capacity details on the lift	🖳	🖳	🖳	
Detailed operating manual	🖳	🖳	🖳	
Condition, function operating lever and	button \square	🛚	🛚	
Label "LIFT, LOWER"	📙	∐		
Condition, lockable main switch				
Condition, rubber plate	📙	∐		
Securing the lifting arm bolts	U	⊔	⊔	
Secure the receiving plate (not unscreve Condition, function carrier plate		□	⊔	
Condition, function foot bumper (optic	⊔ >nal\ □	□		
Condition, function safety catch	лиј ⊔ П	□	□	
Condition sliding part lift rails		□	□	
Paint condition	П			
Load bearing construction (deformations, c	racks) \square	□		
Fastening screw torque		□		
Nuts Cylinder mounting set correctly	П			
Nuts Cylinder Mount: Check Sealing W	ах П			
Fastening anchor torque	🗆	🗆		
Condition, function lifting arm block	🗆	🗆		
Condition, function lifting arm movement	ent 🗆	🗆		
Condition, safety plate on Mini-Max	🗆	🗆	🗆	
Condition, function of Mini-Max lifting of	arm 🗆	🗆	🗆	
Condition of cross-beam	🗆	🗆	🗆	
Cylinder condition	🗆	🗆	🗆	
Condition wiper cylinder	🗆	🗆	🗆	
Condition of covers	🗆	🗆	🗆	
Condition, function riser extension	🗆	🗆	🗆	
Condition of concrete floor (cracks)	🖳	🖳	🖳	
Condition electrical lines	🖳	🖳	🛚	
Condition, hydraulic lines + screw fittings	🖳	∐	∐	
Condition, hydraulic unit	💾	∐		
Functional test lift with vehicle	📙	∐		
Functional test "overflows"				
Stability of lift				
General condition of lift* *) Place a checkmark in the relevant, if a retest			⊔	
Safety inspection done on:				
Performed by company:				
Name address of an acialist				
Name, address of specialist:	Continuo	d aparation o	vuostionablo roi	nspection required
			sible,removedefe	
			sible, removeders lue to operate	ecisby
	LI NO GENCIE	FIICIOS, COLIIII	ide id operale	
Signature of specialist	Operating comp	pany signature		
If requested to take care of deficiencies	es			
Deficiency removed on:				ring company signature
(Use a new form for reinspection!)			Sperar	

OPI-POWER LIFT HF 3S 8000-V1.0-EN



Copy, complete and leave in the inspection book Serial number:					
Test step	OK	Defect missing	Reinspect	Remarks	
Model plate	🗆				
Brief operating instructions on the column	า 🗆	🗆	🗆 💳		
Load capacity details on the lift					
Detailed operating manual	🗆				
Condition, function operating lever and but	tton □	П	П		
Label "LIFT, LOWER"	п — П				
Condition, lockable main switch		Π	<u> </u>		
Condition, rubber plate					
Securing the lifting arm bolts	🗀				
Secure the receiving plate (not unscrewa	□ h a □				
Condition, function carrier plate		□			
Condition, function foot bumper (options					
Condition, function safety catch					
Condition sliding part lift rails	🗀				
Condition sliding part lift rails	🗀				
Paint condition	L	∐			
Load bearing construction (deformations, crace	JKS) ∐	∐			
Fastening screw torque	∐	∐	💾		
Nuts Cylinder mounting set correctly		∐			
Nuts Cylinder Mount: Check Sealing Wax	∶ ⊔	⊔	⊔		
Fastening anchor torque	🗆	🗆	🗆		
Condition, function lifting arm block					
Condition, function lifting arm movement	t 🗆	🗆	🗆		
Condition, safety plate on Mini-Max	🗆	🗆	🗆		
Condition, function of Mini-Max lifting arn	n 🗆	🗆			
Condition of cross-beam	🗆	🗆	🗆		
Cylinder condition	🗆	🗆	🗆		
Condition wiper cylinder	🗆	🗆	🗆		
Condition of covers	🗆	🗆	🗆 💳		
Condition, function riser extension	🗆	🗆	🗆 💳		
Condition of concrete floor (cracks)	🗆	🗆	🗆 💳		
Condition electrical lines	🗆	🗆			
Condition, hydraulic lines + screw fittings	🗖		П		
Condition, hydraulic unit					
Functional test lift with vehicle					
Functional test "overflows"					
Stability of lift					
General condition of lift					
*) Place a checkmark in the relevant, if a retest is re					
Safety inspection done on:					
Performed by company:					
Name a malabase of an 1994					
Name, address of specialist:					
Result of inspection:		•	•	nspection required	
			sible,removedefe	ectsby	
	No deficie	encies, contir	nue to operate		
Signature of specialist Opi	eratina comr	pany signature			
If requested to take care of deficiencies	g 33.11p	,			
Deficiency removed on:					
			Opera	ting company signature	
(Use a new form for reinspection!)					



Condition, function operating lever and button	$\stackrel{\circ}{\mathbb{I}}$ Copy, complete and leave in the in:	spection boo	k Serial num	nber:	
Brief operating instructions on the ecolumn			missing	•	
Load capacity details on the lift	Model plate	🗆	🗆	🗆	
Detailed operating manual.	Brief operating instructions on the colu	mn 🗆	🗆	🗆	
Condition, function operating lever and button	Load capacity details on the lift	🗆	🗆	🗆	
Label "UFT, LOWER"	Detailed operating manual	🗆	🗆	🗆	
Condition, lockable main switch	Condition, function operating lever and I	outton \square	🗆	🗆	
Condition, Nuction (Iffing arm block	Label "LIFT, LOWER"	🗆	🗆	🗆	
Securing the lifting arm bolts	Condition, lockable main switch	🗆	🗆	🗆	
Secure the receiving plate (not unscrewable)	Condition, rubber plate	🗆	🗆	🗆	
Condition, function carrier plate	Securing the lifting arm bolts	🗆	🗆	🗆	
Condition, function foot bumper (optional)					
Condition, function safety catch	Condition, function carrier plate	🗆	🗆	🗆	
Condition, function safety catch	Condition, function foot bumper (optic	onal) 🗆	🗆	🗆	
Paint condition	Condition, function safety catch	🗆	🗆	🗆	
Load bearing construction (deformations, cracks)	Condition sliding part lift rails	🗆	🗆	🗆	
Fastening screw forque	Paint condition	🗆	🗆	🗆	
Nuts Cylinder mounting set correctly					
Nuts Cylinder Mount: Check Sealing Wax	Fastening screw torque	🗆	🗆	🗆	
Fastening anchor torque					
Condition, function lifting arm block	Nuts Cylinder Mount: Check Sealing W	ax 🗆	🗆	🗆	
Condition, function lifting arm movement					
Condition, function of Mini-Max lifting arm					
Condition, function of Mini-Max lifting arm	Condition, function lifting arm moveme	ent 🗆	🗆	🗆	
Condition of cross-beam					
Cylinder condition	Condition, function of Mini-Max lifting of	arm 🗆	🗆	🗆	
Condition wiper cylinder	Condition of cross-beam	🗆	🗆	🗆	
Condition of covers	Cylinder condition	🗆	🗆	🗆	
Condition, function riser extension	Condition wiper cylinder	🗆	🗆	🗆	
Condition of concrete floor (cracks)	Condition of covers	🗆	🗆	🗆	
Condition, hydraulic lines + screw fittings	Condition, function riser extension	🗆	🗆	🗆	
Condition, hydraulic lines + screw fittings	Condition of concrete floor (cracks)	🗆	🗆	🗆	
Condition, hydraulic unit	Condition electrical lines	🗆	🗆	🗆	
Functional test lift with vehicle	Condition, hydraulic lines + screw fittings	🗆	🗆	🗆	
Functional test "overflows"	Condition, hydraulic unit	🗆	🗆	🗆	
Stability of lift	Functional test lift with vehicle	🗆	🗆	🗆	
General condition of lift					
*) Place a checkmark in the relevant, if a retest is required then check it again! Safety inspection done on: Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature					
Safety inspection done on: Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	General condition of lift		🗆	🗆	
Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continuedoperationpossible, removed efects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	*) Place a checkmark in the relevant, if a retest	is required then	check it again!		
Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continuedoperationpossible, removed efects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	Safety inspection done on:				
Result of inspection: Continued operation questionable, reinspection required Continuedoperation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	Performed by company:				
Result of inspection: Continued operation questionable, reinspection required Continuedoperation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	Name address of specialists				
Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature		Continue	d operation o	ruestionable rei	nspection required
Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	kesun or inspection.				
Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature					ecisby
If requested to take care of deficiencies Deficiency removed on: Operating company signature		LI NO delicie	encies, coniir	ive to operate	
Deficiency removed on: Operating company signature	Signature of specialist	Operating comp	pany signature		
Operating company signature	If requested to take care of deficiencies	es			
	Deficiency removed on:			Operation	ting company signature
	(Use a new form for reinspection!)			Opera	ing company signature

OPI-POWER LIFT HF 3S 8000-V1.0-EN



$\stackrel{\circ}{\mathbb{I}}$ Copy, complete and leave in the insp	ection boo	k Serial num	nber:	
Test step	OK	Defect missing	Reinspect	Remarks
Model plate	🗆	🗆	🗆	
Brief operating instructions on the colum	ın 🗆	🗆	🗆	
Load capacity details on the lift	🗆	🗆	🗆	
Detailed operating manual	🗆	🗆	🗆	
Condition, function operating lever and but	utton □	🗆	🗆	
Label "LIFT, LOWER"	🗆	🗆	🗆	
Condition, lockable main switch				
Condition, rubber plate				
Securing the lifting arm bolts	🗆	🗆	🗆	
Secure the receiving plate (not unscrewe	able) 🗆	🗆	🗆	
Condition, function carrier plate	🗆	🗆	🗆	
Condition, function foot bumper (option	nal) 🗆	🗆	🗆	
Condition, function safety catch	🗆	🗆	🗆	
Condition sliding part lift rails	🗆	🗆	🗆	
Paint condition	🗆	🗆	🗆	
Load bearing construction (deformations, cro	ıcks) 🗆	🗆	🗆	
Fastening screw torque	i. 🗆	🗆	🗆	
Nuts Cylinder mounting set correctly	🗆	🗆	🗆 🔣	
Nuts Cylinder Mount: Check Sealing Wa				
Fastening anchor torque	🗆	🗆	🗆 💳	
Condition, function lifting arm block	🗆	🗆		
Condition, function lifting arm movemer	nt 🗆			
Condition, safety plate on Mini-Max			 	
Condition, function of Mini-Max lifting ar	m □			
Condition of cross-beam	··· 🗀			
Cylinder condition				
Condition wiper cylinder		□		
Condition of covers		□		
Condition, function riser extension		□		
Condition of concrete floor (cracks)				
Condition electrical lines		⊔		
Condition by drawlin lines I corey of things				
Condition, hydraulic lines + screw fittings		⊔		
Condition, hydraulic unit				
Functional test lift with vehicle				
Functional test "overflows"				
Stability of lift				
General condition of lift* *) Place a checkmark in the relevant, if a retest is			⊔	
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
	Continue	d operation o	nuestionable rei	nspection required
				ectsby
			nue to operate	JC13Dy
	NO delicie	ericies, corili	ide id operare	
Signature of specialist O _I	perating comp	oany signature		
If requested to take care of deficiencies				
Deficiency removed on:				ting company signature
(Use a new form for reinspection!)			Opera	mig company signature
1000 a new rollin for reinspections;				



\prod Copy, complete and leave in the in	spection boo	k Serial num	nber:	
Test step	OK	Defect missing	Reinspect	
Model plate	🗆	🗆	🗆	
Brief operating instructions on the colu	mn 🗆	🗆	🗆	
Load capacity details on the lift	🖳	🖳	🖳	
Detailed operating manual	🖳	🖳	🖳	
Condition, function operating lever and	button \square	🛚	🛚	
Label "LIFT, LOWER"	📙	∐		
Condition, lockable main switch				
Condition, rubber plate	📙	∐		
Securing the lifting arm bolts	U	⊔	⊔	
Secure the receiving plate (not unscreve Condition, function carrier plate		□	⊔	
Condition, function foot bumper (optic	⊔ >nal\ □	□		
Condition, function safety catch	лиј ⊔ П	□	□	
Condition sliding part lift rails		□	□	
Paint condition	П			
Load bearing construction (deformations, c	racks) \square	□		
Fastening screw torque		□		
Nuts Cylinder mounting set correctly	П			
Nuts Cylinder Mount: Check Sealing W	ах П			
Fastening anchor torque	🗆	🗆		
Condition, function lifting arm block	🗆	🗆		
Condition, function lifting arm movement	ent 🗆	🗆		
Condition, safety plate on Mini-Max	🗆	🗆	🗆	
Condition, function of Mini-Max lifting of	arm 🗆	🗆	🗆	
Condition of cross-beam	🗆	🗆	🗆	
Cylinder condition	🗆	🗆	🗆	
Condition wiper cylinder	🗆	🗆	🗆	
Condition of covers	🗆	🗆	🗆	
Condition, function riser extension	🗆	🗆	🗆	
Condition of concrete floor (cracks)	🖳	🖳	🖳	
Condition electrical lines	🖳	🛚	🛚	
Condition, hydraulic lines + screw fittings	🖳	∐	∐	
Condition, hydraulic unit	💾	∐		
Functional test lift with vehicle	📙	∐		
Functional test "overflows"				
Stability of lift				
General condition of lift* *) Place a checkmark in the relevant, if a retest			⊔	
Safety inspection done on:				
Performed by company:				
Name address of an acialist				
Name, address of specialist:	Continuo	d aparation o	vuostionablo roi	nspection required
			sible,removedefe	
			sible, removeders lue to operate	ecisby
	LI NO GENCIE	FIICIOS, COLIIII	ide id operale	
Signature of specialist	Operating comp	pany signature		
If requested to take care of deficiencies	es			
Deficiency removed on:				ring company signature
(Use a new form for reinspection!)			Sperar	

OPI-POWER LIFT HF 3S 8000-V1.0-EN



Model plate	$\stackrel{\circ}{\mathbb{I}}$ Copy, complete and leave in the ins	spection boo	k Serial num	nber:	
Model plate Brief operating instructions on the column	Test step	OK		Reinspect	Remarks
Bilef operating instructions on the eolumn	Model plate	🗆			
Load capacity details on the lift	Brief operating instructions on the colur	mn □	🗆		
Detailed operating manual.					
Condition, function operating lever and button	Detailed operating manual	П			
Label "UFT, LOWER"	Condition function operating lever and h	outton \square		П	
Condition, lockable main switch	Label "LIFT LOWER"	лон <u>П</u>	 П		
Condition, rubber plate Securia the lifting arm bolts Securia the lifting arm bolts Securia the receiving plate (not unscrewable) Condition, function carrier plate Condition, function foot bumper (potional). Condition, function safety catch. Condition, function safety catch. Condition, stading part lift rails Point condition Condition stading part lift rails Condition stading part lift rails Condition stading part lift rails Condition function (deformations, cracks) Fastening screw torque Nuts Cylinder mounting set correctly Nuts Cylinder mounting set correctly Nuts Cylinder mounting set correctly Condition, function lifting arm block Condition, function lifting arm block Condition, function lifting arm movement Condition, function iffing arm wovement Condition, function of Mini-Max lifting arm Condition, function of Mini-Max lifting arm Condition wiper cylinder Condition of cross-beam Condition of corss-beam Condition of correcte floor (cracks) Condition of correcte floor (cracks) Condition of part of corrected floor Condition, function lifting Condition of part with vehicle Functional test lift with vehicle Condition of the lift with vehicle Condition of the lift with vehicle Condition of condition of lift I Place a checkmark in the relevant, if a relest is required then check it again! Safety inspection done on: Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate If requested to take care of deficiencies Deficiency removed on: Operating company signature	Condition lockable main switch		 П		
Securing the lifting arm bolts	Condition rubber plate		□		
Secure the receiving plate (not unscrewable)	Securing the lifting arm holts				
Condition, function carrier plate Condition, function safety catch	Secure the receiving plate (not unscrew	/able) □			
Condition, function foot bumper (optional).	Condition function carrier plate				
Condition, function safety catch.	Condition function foot humber (ontice	□ .nall □			
Condition sliding part lift rails	Condition function safety catch	лы, <u> </u>			
Paint condition	Condition sliding part lift rails				
Load bearing construction (deformations, cracks)	Paint condition	□	□		
Fastening screw torque	Load hearing construction (deformations of	□ racks) □	⊔ □		
Nuts Cylinder mounting set correctly	Fastening screw torque	uск) ⊔	⊔ □		
Nuts Cylinder Mount: Check Sealing Wax	Nuts Cylinder mounting set correctly	□	⊔ ⊓		
Fastening anchor torque	Nuts Cylinder Mount: Check Sealing W.		⊔ ⊓		
Condition, function lifting arm block	Fastoning anchor torque	ux ⊔	□		
Condition, function lifting arm movement	Condition function lifting arm block	□	□		
Condition, safety plate on Mini-Max					
Condition of cross-beam					
Condition of cross-beam	Condition function of Mini May lifting a	□	□		
Cylinder condition	Condition of cross boars	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			
Condition wiper cylinder	Cylinder condition		⊔		
Condition of covers	Condition winer evlinder				
Condition, function riser extension	Condition of covers				
Condition of concrete floor (cracks)	Condition function riser extension				
Condition, hydraulic lines + screw fittings	Condition of concrete floor (cracks)		⊔		
Condition, hydraulic lines + screw fittings	Condition electrical lines				
Condition, hydraulic unit	Condition by drawling lines I serow fittings				
Functional test lift with vehicle					
Functional test "overflows"					
Stability of lift					
General condition of lift					
*) Place a checkmark in the relevant, if a retest is required then check it again! Safety inspection done on: Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	SIGDIIIY OI III	⊔			
Performed by company: Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continuedoperationpossible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	*) Place a checkmark in the relevant, if a retest	is required then	check it again!	⊔	
Name, address of specialist: Result of inspection: Continued operation questionable, reinspection required Continuedoperationpossible, removed efects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature	Safety inspection done on:				
Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	Performed by company:				
Result of inspection: Continued operation questionable, reinspection required Continued operation possible, remove defects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature Operating company signature	Name address of specialist				
Continued operation possible, removed effects by No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: Operating company signature		7 Continue	d operation o	ruestionable rei	nspection required
□ No deficiencies, continue to operate Signature of specialist Operating company signature If requested to take care of deficiencies Deficiency removed on: □ Operating company signature	_				
If requested to take care of deficiencies Deficiency removed on: Operating company signature	_				
Deficiency removed on: Operating company signature	Signature of specialist	Operating comp	pany signature		
Deficiency removed on: Operating company signature	If requested to take care of deficiencie	es .			
	·				the second secon
	(Use a new form for reinspection!)			Opera:	ning company signature



Copy, complete and leave in the inspection book Serial number:						
Test step	OK	Defect missing	Reinspect			
Model plate	🗆	🗆	🗆			
Brief operating instructions on the colu	mn 🗆	🗆	🗆			
Load capacity details on the lift	🖳	🖳	🖳			
Detailed operating manual	🖳	🖳	🛚			
Condition, function operating lever and	button \square	🛚	🛚			
Label "LIFT, LOWER"	📙	∐				
Condition, lockable main switch						
Condition, rubber plate	📙	∐				
Securing the lifting arm bolts	U	⊔	⊔			
Secure the receiving plate (not unscreve Condition, function carrier plate	wabiej ⊔	□	⊔			
Condition, function foot bumper (option		□				
Condition, function safety catch	Jiiaij □	□	□			
Condition sliding part lift rails		□	□			
Paint condition						
Load bearing construction (deformations, c	cracks) \square	□				
Fastening screw torque		□				
Nuts Cylinder mounting set correctly						
Nuts Cylinder Mount: Check Sealing W	'ax □					
Fastening anchor torque	🗆	🗆				
Condition, function lifting arm block	🗆	🗆				
Condition, function lifting arm movem	ent 🗆	🗆				
Condition, safety plate on Mini-Max	🗆	🗆	🗆			
Condition, function of Mini-Max lifting	arm 🗆	🗆				
Condition of cross-beam	🗆	🗆	🗆			
Cylinder condition	🗆	🗆	🗆			
Condition wiper cylinder	🗆	🗆	🗆			
Condition of covers	🗆	🗆	🗆			
Condition, function riser extension	🗆	🗆	🗆			
Condition of concrete floor (cracks)	🛚	🖳	🖳			
Condition electrical lines	🛚	🖳	🛚			
Condition, hydraulic lines + screw fittings	🖳	∐	∐			
Condition, hydraulic unit	∐	∐				
Functional test lift with vehicle	📙	∐				
Functional test "overflows"						
Stability of lift						
General condition of lift* *) Place a checkmark in the relevant, if a retest			⊔			
Safety inspection done on:						
Performed by company:						
Name address of as a signist						
Name, address of specialist:	Continuo	d aparation o	u ostionablo roi	nspection required		
				ectsby		
			sible, removeders lue to operate	ecisby		
	L NO delicie	FIICIOS, COLIIII	ide id operale			
Signature of specialist	Operating comp	oany signature				
If requested to take care of deficienci	es					
Deficiency removed on:				ing company signature		
(Use a new form for reinspection!)			Operar	g company signatore		

OPI-POWER LIFT HF 3S 8000-V1.0-EN



9.3 Exceptional safety inspection

$\stackrel{\circ}{\mathbb{I}}$ Copy, complete and leave in the insp	ection boo	k Serial nun	nber:	
Test step	OK	Defect missing	Reinspect	Remarks
Model plate	🗆		🗆	
Brief operating instructions on the column	n 🗆	🗆	🗆 💳	
Load capacity details on the lift				
Detailed operating manual	🗖			
Condition, function operating lever and bu	tton 🗆		П	
Label "LIFT, LOWER"	П		П ——	
Condition, lockable main switch	П		П ——	
Condition, rubber plate				
Securing the lifting arm bolts				
Secure the receiving plate (not unscrewa	□ ıhlal □			
Condition, function carrier plate				
Condition, function foot bumper (option				
Condition, function safety catch				
Condition sliding part lift rails	∐	📙		
Paint condition	∐	∐		
Load bearing construction (deformations, crae	cks) ⊔	⊔	⊔	
Fastening screw torque	🗆	🗆	🗆	
Nuts Cylinder mounting set correctly	🗆	🗆	·····	
Nuts Cylinder Mount: Check Sealing Wax	< □	🗆	🗆	
Fastening anchor torque	🗆	🗆	🗆	
Condition, function lifting arm block	🗆	🗆	🗆	
Condition, function lifting arm movemen				
Condition, safety plate on Mini-Max	🗆	🗆	🗆 💳	
Condition, function of Mini-Max lifting arr	n 🗆			
Condition of cross-beam			П	
Cylinder condition				
Condition wiper cylinder				
Condition of covers				
Condition, function riser extension			········ ¦	
Condition of concrete floor (cracks)				
Condition algebra discontinuo				
Condition electrical lines	∐	📙		
Condition, hydraulic lines + screw fittings				
Condition, hydraulic unit				
Functional test lift with vehicle				
Functional test "overflows"				
Stability of lift				
General condition of lift			🗆	
*) Place a checkmark in the relevant, if a retest is r	required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	Continue	d operation a	guestionable, rei	nspection required
		•	sible,removedefe	·
			nue to operate	
	NO delicit	oricios, cornii	ide la operare	
Signature of specialist Op	erating comp	oany signature		
If requested to take care of deficiencies				
Deficiency removed on:				ting company signature
(Use a new form for relies a stier !)			Opera	ting company signature
(Use a new form for reinspection!)				




Spare parts list

POWER LIFT HF 3S 8000





Cylinder operator side




1 240HLNT02550 2 240HLNT02540 CYLINDER FOLLOW. ASSY. CYLINDER COM. ASSY.

3 230SLNT02819

GROOVE NUT 4 230SLNT22821 ANTI-TWIST SAFETY



Opposite side cylinder




1 240HLNT02550 2 240HLNT02540 CYLINDER FOLLOW. ASSY. CYLINDER COM. ASSY.

3 230SLNT02819 4 230SLNT22818

GROOVE NUT ANTI-TWIST SAFETY



Operator side column complete






1	230SLNT05560 HEAD PLATE OPERATOR SIDE	8	9912-M5X10 CYLINDER SCREW
	COMPLETE	9	9912-M6X10 CYLINDER SCREW
2	230HLNT25013 OPERATOR SIDE COLUMN	10	240SL09008 COVER PANEL
	WELDED PART	11	230SLH09045 COVER HOOD
3	9934-M10 HEXAGONAL NUT	12	230SLH09048 COVER HOOD
4	9125_1-A10_5 WASHER	13	230SLNT05008 LIFT RAILS
5	9125_1-A5_3 WASHER	14	970010 ROSETTE
6	97991-M5X12 COUNTERSUNK SCREW	15	970721 CLOSING STOPPER
7	97991-M5X16 COUNTERSUNK SCREW		




Opposite side column complete



1	230SLNT05530	HEAD PLATE OPPOSITE SIDE	9	9912-M5X10	CYLINDER SCREW
		COMPLETE	10	9912-M6X10	CYLINDER SCREW
2	230HLNT25023	OPPOSITE SIDE COLUMN	11	225SL09021	COVER PANEL FOR E-SET
		WELDED PART.	12	240SL09008	COVER PANEL
3	9934-M10	HEXAGONAL NUT	13	230SLH09047	COVER HOOD
4	9125_1-A10_5	WASHER	14	230SLH09048	COVER HOOD
5	9125_1-A5_3	WASHER	15	230SLNT05008	LIFT RAILS
6	97991-M5X12	COUNTERSUNK SCREW	16	970010	ROSETTE
7	97991-M5X16	COUNTERSUNK SCREW	17	970721	CLOSING STOPPER
8	97991-M5X8	COUNTERSUNK SCREW			



Universal unit




- 1 240HLNT21560 CASE ASSY.
- 2 240 HLNT01582 HOOD USA ASSY.
- 3 000STA11580 LEVER ASSY.

- 4 240HLNT01580 HYDRAULIC PLUG-IN UNIT ASSY.
- 5 240SLK01100 BOSCH UNIT USA (LEVER)




Operating side latch holder



1	240HLNTK25420	LATCH MOUNTING ASSEMBLY	7	9SEM08X012ZN	FLANGED BUTTON HEAD
2	240HLNTK25403	OPERATING SIDE LATCH			SCREW
		HOLDER WELDED PART	8	97380M03X06ZN	FILLISTER HEAD SCREW
3	00MNG603160	MAGNET NG6	9	9988D012X018X1PS	SHIM RING
4	9985-M4	HEXAGONAL NUT DIN985	10	96799_10ZN	LOCKING WASHER
5	240HLNTK05429	LATCH BOLT	11	9912M4X20ZN	CYLINDER SCREW
6	240HLNTK05425	RATCHET SLIDER			




Opposite side latch holder



1	240HLNTK05430	LATCH MOUNTING ASSEMBLY	7	9SEM08X012ZN	FLANGED BUTTON HEAD
2	240HLNTK25503	OPPOSITE SIDE LATCH			SCREW
		HOLDER WELDED PART	8	97380M03X06ZN	FILLISTER HEAD SCREW
3	00MNG603160	MAGNET NG6	9	9988D012X018X1PS	SHIM RING
4	9985-M4	HEXAGONAL NUT DIN985	10	96799_10ZN	LOCKING WASHER
5	240HLNTK05429	LATCH BOLT	11	9912M4X20ZN	CYLINDER SCREW
6	240HLNTK05425	RATCHET SLIDER			




Lift rails operator side complete



1	240HLNT26003	LIFT RAILS WELDED PARTS	11	97346-3X20 FRICTION BOLT
		OPERATOR SIDE	12	97984-M10X20 CYLINDER SCREW
2	240HLNT06083	LATCH WELDED PART	13	DFD-222SL01ZN PRESSURE SPRING 155MM
3	245SPL28095	DRAWBAR WELDED PART	14	225SL06033 SLIDING PIECE
4	245SPL28096	DRAWBAR WELDED PART	15	225SL06036 SLIDING PIECE
5	ET 9934-M5	HEXAGONAL NUT	16	225SL06038 SLIDING PIECE
6	9934-M6	HEXAGONAL NUT	1 <i>7</i>	230SLH06033 SLIDING PIECE
7	9982-M10	HEXAGONAL NUT	18	225SL06103S1 RUBBER PROFILE
8	9931_1-M10X45	HEXAGONAL SCREW		400MM (970194)
9	97991-M5X16	COUNTERSUNK SCREW	19	9SEM08X020ZN LINSENFLANSCHSCHRAUBE
10	97991-M6X16	COUNTERSUNK SCREW		




Lift rails opposite side complete



1	240HLNT26053	LIFT RAILS WELDED PARTS	11	97346-3X20 FRICTION BOLT
		OPPOSITE PARTS	12	97984-M10X20 CYLINDER SCREW
2	240HLNT06083	BLATCH WELDED PART	13	DFD-222SL01ZN PRESSURE SPRING 155MM
3	245SPL28095	DRAWBAR WELDED PART	14	225SL06033 SLIDING PIECE
4	245SPL28096	DRAWBAR WELDED PART	15	225SL06036 SLIDING PIECE
5	9934-M5	HEXAGONAL NUT	16	225SL06038 SLIDING PIECE
6	9934-M6	HEXAGONAL NUT	17	230SLH06033 SLIDING PIECE
7	9982-M10	HEXAGONAL NUT	18	225SL06103S1 RUBBER PROFILE
8	9931_1-M10X45	HEXAGONAL SCREW		400MM (970194)
9	97991-M5X16	COUNTERSUNK SCREW	19	9SEM08X020ZN LINSENFLANSCHSCHRAUBE
10	97991-M6X16	COUNTERSUNK SCREW		




Universal control with circuit board



000STA03600_1 29.05.2018







232SL08210 T4 ARM SHORT
 235SLNT08001 LONG LIFTING ARM

3 235SLNT08010 LONG LIFTING ARM










- 232NSTL28038 T4 ARM SHORT
- 2 240SPL08001 OPERATING SIDE LONG LIFTING ARM

240SPL08002 OPPOSITE SIDE LONG LIFTING ARM





1	235HLNT08001 OPERATING SIDE LIFTING ARM	3	235SL08051	OPERATING SIDE LIFTING ARM
	DG-MM (FLAT VERSION)			SHORT
2	235HLNT08002 OPPOSITE SIDE LIFTING ARM	4	235SL08052	OPPOSITE SIDE LIFTING ARM
	DG-MM (FLAT VERSION)			SHORT



Dealer address/phone:	



Nussbaum Automotive Solutions, LP • 1932 Jordache Court • Gastonia, NC 28052 www.nussbaum-usa.com • E-Mail: warranty@nussbaum-usa.com

Fax: 1-704-864-2476

Service Hotline International: +49 180-5 288 911

OPI-POWER LIFT HF 3S 8000-V1.0-EN_012020 - Artikelnummer: 975537